

M E N U

1 . V I D E O . O U T

P A L

2 . L A N G U A G E

E N G ↵

3 . S E T U P

↵

SETUP

1.	SCENE	INDOOR
2.	LENS	MANUAL
3.	EXP	↵
4.	ISO	OFF
5.	WB	ATW
6.	DAY & NIGHT	AUTO ↵
7.	NR	↵
8.	SPECIAL	↵
9.	ADJUST	↵
10.	RESET	↵
11.	EXIT	↵

EXPOSURE

1. SHUTTER	AUTO
2. AGC	 6
3. SENS-UP	OFF
4. BRIGHTNESS	 3 6
5. D-WDR	OFF
6. DEFOG	OFF
7. RETURN	RET

SENS-UP

1. SENS-UP

× 2

2. RETURN

RET

DEFOG

- | | | |
|----|------------|-----|
| 1. | POS / SIZE | ↵ |
| 2. | GRADATION | OFF |
| 3. | DEFAULT | ↵ |
| 4. | RETURN | RET |



P O S I T I O N





S I Z E



W D R

1. G A I N

H I G H

2. W D R B R I G H T

.....|..... 3 8

3. W D R O F F S E T


|..... 0


4. R E T U R N

R E T

B L C

1.	G A I N	M I D D L E
2.	A R E A	↵
3.	D E F A U L T	↵
4.	R E T U R N	R E T





H L C

1. G A I N

M I D D L E

2. A R E A

↙

3. D E F A U L T

↙

4. R E T U R N

R E T




P O S I T I O N





S I Z E



MANUAL WB

1. BLUE

||||| | 50

2. RED

||||| | 50

3. RETURN

RET

AUTO

1. I R L E D

O N

2. RETURN

R E T

2 D & 3 D N R

1. 2 D N R

0 N

2. 3 D N R

0 N ↙

3. RETURN

RET

3 D N R

1 . S M A R T N R

0 N ↵

2 . L E V E L

||||||| | | | | | 6 8

3 . S T A R T . A G C

| | | | | | | | | | 0

4 . E N D . A G C

| | | | | | | | | | 0

5 . R E T U R N

R E T

3D SMART NR

1. SENSITIVITY

80

2. RETURN

RET

SPECIAL

1.	CAM	TITLE	OFF
2.	D-E	FECT	↵
3.	MOTION		OFF
4.	PRIVACY		OFF
5.	DEFECT		↵
6.	VOLTAGE	DET.	OFF
7.	RETURN		RET

C A M T I T L E

	0	1	2	3	4	5	6	7	8	9
A	B	C	D	E	F	G	H	I	J	K
L	M	N	O	P	Q	R	S	T	U	V
W	X	Y	Z	▶	→	←	↑	↓	(	)
—	—	—	■	/	=	&	:	~	,	.

← → C L R P O S E N D

D-EFFECT

1.	F	R	E	E	Z	E				0	F	F	
2.	M	I	R	R	O	R				0	F	F	
3.	D	-	Z	O	O	M				0	F	F	
4.	S	M	A	R	T		D	-	Z	O	O	M	
5.	N	E	G	.	I	M	A	G	E		0	F	F
6.	R	E	T	U	R	N					R	E	T

D-ZOOM

- | | | |
|-------------|-----|-----|
| 1. D-ZOOM | × | 2.0 |
| 2. PAN&TILT | ↓ | |
| 3. DEFAULT | ↓ | |
| 4. RETURN | RET | |



D - Z O O M



SMART D-ZOOM

1. SELECT	AREA 1
2. DISPLAY	ON ↵
3. SENSITIVITY	30
4. D-ZOOM	× 2.0
5. TIME	3
6. DEFAULT	↵
7. RETURN	RET



P O S I T I O N



MOTION

1. SELECT

2. DISPLAY

3. SENSITIVITY

4. MOTION VIEW

5. DEFAULT

6. RETURN

AREA 4


ON ↵

..... 30

OFF


↵

RET




P O S I T I O N





S I Z E







PRIVACY



1. SELECT
2. DISPLAY
3. COLOR
4. TRANS.
5. DEFAULT
6. RETURN

AREA 1
INV. ↵
1 4
3
↵
RET







P O S I T I O N









TOP LEFT








TOP RIGHT






BOTTOM LEFT





BOTTOM RIGHT



DEFECT

1. LIVE DPC ON ↵
2. STATIC DPC ON ↵
3. RETURN RET

L I V E D P C

1 . L E V E L

||||| | 5 0

2 . R E T U R N

R E T

STATIC DPC

1. START	↵
2. LEVEL	 5
3. SENS-UP	× 4
4. AGC	 8
5. RETURN	RET

ADJUST

- | | |
|--------------|-------|
| 1. SHARPNESS | 8 |
| 2. MONITOR | LCD ↵ |
| 3. LSC | OFF |
| 4. RETURN | RET |

L C D

1 . G A M M A

U S E R

2 . B L U E G A I N

.....|..... 7 6

3 . R E D G A I N

.....|..... 7 6

4 . R E T U R N

R E T

CRT

1 .	B L A C K	L E V E L	- 3 0
2 .	B L U E	G A I N	+ 3 0
3 .	R E D	G A I N	+ 3 0
4 .	R E T U R N		R E T

RESET

1. FACTORY

2. RETURN

RESET ↵

RET