

MAIN MENU

VIDEO FORMAT

◀ 2M25 ▶

EXPOSURE

↵

VIDEO SETTINGS

↵

SMART LIGHT

↵

FUNCTIONS

↵

FACTORY DEFAULT

↵

EXIT

↵

SAVE&EXIT

↵

EXPOSURE

EXPOSURE MODE

◀ GLOBAL ▶

AGC

◀ LOW ▶

SLOW SHUTTER

◀ OFF ▶

BACK

↵

EXIT

↵

SAVE&EXIT

↵

EXPOSURE

EXPOSURE MODE

◀ B L C ▶

A G C

◀ L O W ▶

S L O W S H U T T E R

◀ O F F ▶

B A C K

↵

E X I T

↵

S A V E & E X I T

↵

EXPOSURE

EXPOSURE MODE

◀ WDR ▶

AGC

◀ LOW ▶

SLOW SHUTTER

◀ OFF ▶

BACK

↵

EXIT

↵

SAVE&EXIT

↵

VIDEO SETTINGS

WHITE BALANCE



BRIGHTNESS

◀ 5 ▶

CONTRAST

◀ 5 ▶

SHARPNESS

◀ 5 ▶

SATURATION

◀ 5 ▶

3DNR

◀ 6 ▶

MIRROR

◀ OFF ▶

BACK



EXIT



SAVE&EXIT



WHITE BALANCE

MODE

◀ AUTO ▶

BACK

↵

EXIT

↵

SAVE&EXIT

↵

WHITE BALANCE

MODE

◀ MANUAL ▶

R - GAIN

◀ 18 ▶

B - GAIN

◀ 6 ▶

BACK

↵

EXIT

↵

SAVE & EXIT

↵

SMART LIGHT

MODE

◀ OFF ▶

BACK

↵

EXIT

↵

SAVE & EXIT

↵

SMART LIGHT

MODE

◀ AUTO ▶

THRESHOLD

◀ 2 ▶

LEVEL

◀ 5 ▶

BACK

↵

EXIT

↵

SAVE&EXIT

↵

FUNCTIONS

PRIVACY



MOTION



DPC

◀ OFF ▶

BACK



EXIT



SAVE&EXIT



PR I V A C Y

MODE

◀ ON ▶

AREA 0

↵

AREA 1

↵

AREA 2

↵

AREA 3

↵

COLOR

◀ RED ▶

TRANSPARENCY

◀ OFF ▶

BACK

↵

EXIT

↵

SAVE&EXIT

↵

AREA 0

DISPLAY

◀ ON ▶

X POSITION

◀ 13 ▶

Y POSITION

◀ 6 ▶

WIDTH

◀ 30 ▶

HEIGHT

◀ 33 ▶

BACK

↵

EXIT

↵

SAVE&EXIT

↵

MOTION

MODE

◀ ON ▶

AREA 0

↵

AREA 1

↵

AREA 2

↵

AREA 3

↵

SENSITIVITY

◀ 50 ▶

COLOR

◀ RED ▶

TRANSPARENCY

◀ OFF ▶

BACK

↵

EXIT

↵

SAVE&EXIT

↵

AREA 0

DISPLAY

◀ ON ▶

X POSITION

◀ 13 ▶

Y POSITION

◀ 6 ▶

WIDTH

◀ 30 ▶

HEIGHT

◀ 33 ▶

BACK

↵

EXIT

↵

SAVE&EXIT

↵