

Main Menu

>Format	PAL↵
Video Mode	4M↵ CVI
Backlight Mode	Off
Image Adjust	↵
Exposure	↵
White Balance	Auto
Day/Night	Auto↵
Language	English
Advanced	↵
Default	
Exit	

Backlight Mode

>BLC On

Return

Backlight Mode

>WDR 3

Return

Backlight Mode

>HLC 3

Return

Image Adjust

>Image Mode	Standard
Sharpness	7
Brightness	7
Contrast	7
Saturation	7
Chroma	7
Gamma	7
2DNR	7
Return	

Exposure

>Exposure Mode Auto↵
Exposure Level 7
Anti-flicker Outdoor
Return

Auto Exposure

>Gain Max Limit 12

Gain Min Limit 0

Return

Low Noise

>Gain Max Limit 12

Return

Anti-smear

>Shutter Max 40ms
Return

Manual Exposure

>Shutter 1/25

Gain Max Limit 12

Gain Min Limit 0

Return

WB Manual

>Blue Gain	50
Red Gain	50
Return	

Area WB

>Area Setting Location↓
Return



OK



Day/Night

>Day/Night	6
Night/Day	12
Waiting Time	2
Return	

Advanced

>Camera Name	Off
Mirror	↓
Audio Mode	Built-in Mic↓
IR	On
Smart IR	6
Voltage Prompt	On↓
Privacy Mask	Off
System Info	↓
Video Type	CVI
Return	

Camera Name

>Name ↵

Location ↵

Return

Camera Name

00000000

—

Mirror

>H-Mirror Off

V-Mirror Off

Return

Audio Mode

>Volume

Medium

Return

Voltage Prompt

>Alarm Upload On

Return

Privacy Mask



>Area Select 0
Display On
Area Setting Location↵
Default
Return



OK



System Info

Version No.

V1.000.0000000.2.R

>Return