

Alarm Control Panel **PERFECTA LTE**

Firmware Version 1.04



LIST OF SERVICE FUNCTIONS

perfecta_lte_lf_en 07/20

SATEL sp. z o.o.
ul. Budowlanych 66 • 80-298 Gdańsk • POLAND
tel. +48 58 320 94 00
www.satel.eu

Alarm system

Owner

Address.....

Phone number

Notes.....

.....

.....

.....

.....

.....

.....

1. Introduction

This document presents the list of functions available in the service mode menu. In the square brackets you will find factory default setting (if the parameter is defined / option enabled).

1.1 Starting the service mode

1. Enter the **service code** (by default: 12345) and press .
2. User menu appears.
3. Press .
4. When the  cursor shows the SERVICE MODE function, press .
5. Service mode menu will be displayed (the  cursor will show the END SM function).

1.2 Navigating through the menu and running functions

To navigate throughout the menu, you can use the arrow keys or number shortcuts. You can also combine the two methods. The cursor  shows the submenu you can enter / function you can run.

1.2.1 Using the arrow keys

1. Using the  and  keys, find the required submenu.
2. Press  or  to open a submenu (use the  key to go back to the main menu).
3. Repeat the steps 1 and 2 until the required function is found.
4. Press  or  to run the function.

1.2.2 Using the number shortcuts

Submenus and functions are numbered.

1. Use the number keys to enter the number (use the  key to erase the last digit).
2. The menu item designated by this number will be displayed (use the  key to go back to the main menu).
3. Press  or  to open a submenu or run a function.

If the cursor  indicates END SM and you want to quickly run a function, enter its number and press  or . For example, to run the expander identification function, press successively   .

If the cursor  indicates an item different from END SM, entering a digit will add this digit at the end of the number by which the item displayed in the menu is designated. New digits are always added at the end of the number displayed (only the END SM function is not numbered). For example, if the cursor  indicates a menu item with the 31 (31.EOL) number, pressing   in turn will display the 3132 (3132.Zn.32 EOL) item, not the 32 (32.SENSITIVITY) item. To display the 32 (32.SENSITIVITY) item, you should press  (to move the cursor  down) or   (to erase 1 and add 2).

If you remember the submenu/function number and you want to avoid mistakes, press  before entering the number.

1.3 Data editing

The editing method depends on the type of data. Having completed the editing, press  to save the changes. If you want to exit the function without saving the changes, press .

1.3.1 Selection from the single-choice list

In the lower line of the display, the currently selected item is presented. You can scroll the list using the  and  keys.

1.3.2 Selection from the multiple-choice list

In the lower line of the display, one of the items you can choose from is presented. You can scroll the list using the  and  keys. The following symbol is situated in the upper right corner of the display:

-  – displayed item is selected / option is enabled,
- – displayed item is not selected / option is disabled.

Press any number key to change the currently shown symbol for another one.

If you want to see the status of all items (these can be e.g. zones, outputs, options, etc.), press  or . The numbers around the display allow the items to be identified. Use the  and  keys to move the cursor. After hovering the cursor over the selected item, you can change its status by pressing any number key. If you want to restore the previous way of presentation of the list, press  or .

1.3.3 Entering decimal values

To enter digits, use the number keys. Use the  and  keys to move the cursor. In some functions, the  key deletes the character on the left side of the cursor.

1.3.4 Entering hexadecimal values

To enter digits, use the number keys. To enter the A, B and C characters, use the  key, and to enter D, E and F, use the  key (keep pressing the key until the required character appears). Use the  and  keys to move the cursor. The  key deletes the character on the left side of the cursor.

1.3.5 Programming telephone numbers

To enter digits, use the number keys. To enter the +, *, # characters, use the  key (keep pressing the key until the required character appears). Use the  and  keys to move the cursor. The  key deletes the character on the left side of the cursor.

1.3.6 Entering names

The characters that can be entered by using the keys are presented in Table 1. Keep pressing the key until the required character appears. Long press the key to display the digit assigned to it.

Shown on the right side in the upper line of the display is information about the letter case: [ABC] or [abc] (it will be displayed after pressing any key and will be visible for a few seconds after the last keystroke).

Use the  and  keys to move the cursor. The  key deletes the character on the left side of the cursor.

Key	Characters available after next keystroke															
1	!	?	'	`	↵	"	{	}	\$	%	&	@	\	^		☞
2 ^{ABC}	a	b	c	2												
3 ^{DEF}	d	e	f	3												
4 ^{GHI}	g	h	i	4												
5 ^{JKL}	j	k	l	5												
6 ^{MNO}	m	n	o	6												
7 ^{PQRS}	p	q	r	s	7											
8 ^{TUV}	t	u	v	.	☐	■	☐	↑	←	÷	↓					
9 ^{WXYZ}	w	x	y	z	9											
0 [☐]		.	,	:	;	+	-	*	/	=	_	<	>	(	)	[] 0

Table 1. Characters available when entering names. The upper case letters are available under the same keys (to change the letter case, press **☒☑**).

1.4 Hiding the service mode

You can hide the service mode by using the 09.HIDE SM function. The control panel will remain in the service mode, but the service mode menu will not be displayed. The function can be useful e.g. when you have to leave the keypad, but you want to prevent unauthorized personnel from getting access to the service menu in the meantime. To get access to the menu again, proceed in the same way as when entering the service mode.

1.5 Exiting the service mode

Keep pressing ***☑** until the cursor **➔** indicates the SM END function, and then press **#☐**.

2. Service mode menu

End SM

0.System

00.Service code [12345]

01.PERFECTA key

02.Factory set.

03.SM config

SM sounds [✓] Block SM

04.PERFECT.Soft

041.Address

042.Port

05.Remot.update

051.Address

052.Port

06.Time

061.DST [UE standard]

062.Summer from

063.Winter from

064.Timezone [UTC +01:00]

065.RTC adjust.

09.Hide SM

1.Partitions

13.Exit delay

131.Exit del.p1 [30 s]

132.Exit del.ps2 [30 s]

14.Warn.delay

141.Warn.del.p1 [30 s]

142.Warn.del.p2 [30 s]

15.Verif.delay

151.Verf.del.p1

152.Verf.del.p2

16.Options

161.P.1 options

Infini.ex.delay Entry del. night [✓]

Fin. exit delay [✓] Entry del. day [✓]

162.P.2 options

Infini.ex.delay Entry del. night [✓]

Fin. exit delay [✓] Entry del. day [✓]

18.Names

181.Partition 1 [Partition 1]

182.Partition 2 [Partition 2]

2.Expanders

20.Kpd.address.

21.Identificat.

22.Partitions

220.Kpd.0 part.	 [Partition 1]
221.Kpd.1 part.	 [Partition 1]
222.Kpd.2 part.	 [Partition 1]
223.Kpd.3 part.	 [Partition 1]
227.Ex.07 part	 [Partition 1]
2212.Ex.0C part	 [Partition 1]
2213.Ex.0D part	 [Partition 1]
2214.Ex.0E part	 [Partition 1]
2215.Ex.0F part	 [Partition 1]
23.Max.AC loss	
2312.AC.0C loss	 [1 min]
2313.AC.0D loss	 [1 min]
2314.AC.0E loss	 [1 min]
2315.AC.0F loss	 [1 min]
24.Chime	
240.Kpd.0 chime	
241.Kpd.1 chime	
242.Kpd.2 chime	
243.Kpd.3 chime	
25.Volume	
251.Keys	
2510.Keys 0	 [25%]
2511.Keys 1	 [25%]
2512.Keys 2	 [25%]
2513.Keys 3	 [25%]
252.Chime	
2520.Chime 0	 [100%]
2521.Chime 1	 [100%]
2522.Chime 2	 [100%]
2523.Chime 3	 [100%]
253.Entry delay	
2530.Entry 0	 [100%]
2531.Entry 1	 [100%]
2532.Entry 2	 [100%]
2533.Entry 3	 [100%]
254.Exit delay	
2540.Exit 0	 [25%]
2541.Exit 1	 [25%]
2542.Exit 2	 [25%]
2543.Exit 3	 [25%]
255.Fire alarm	
2550.Fire 0	 [100%]
2551.Fire 1	 [100%]
2552.Fire 2	 [100%]
2553.Fire 3	 [100%]
256.Burg.alarm	
2560.Burg.0	 [100%]

2561.Burg.1	[100%]
2562.Burg.2	[100%]
2563.Burg.3	[100%]
257.Warn.alarm	
2570.Warn.0	[100%]
2571.Warn.1	[100%]
2572.Warn.2	[100%]
2573.Warn.3	[100%]
258.New trouble	
2580.New trbl.0	 [25%]
2581.New trbl.1	 [25%]
2582.New trbl.2	 [25%]
2583.New trbl.3	 [25%]
26.LCDbacklight	
260.LCD bl.0	 [auto 0-50%]
261.LCD bl.1	 [auto 0-50%]
262.LCD bl.2	 [auto 0-50%]
263.LCD bl.3	 [auto 0-50%]
27.KEYbacklight	
270.KEY bl.0	 [auto]
271.KEY bl.1	 [auto]
272.KEY bl.2	 [auto]
273.KEY bl.3	 [auto]
28.Names	
280.Kpd.0 name	[PRF-LCD 0}
281.Kpd.1 name	[PRF-LCD 1}
282.Kpd.2 name	[PRF-LCD 2}
283.Kpd.3 name	[PRF-LCD 3}
287.Ex.07 name	 [INT-RX-S 0x07]
2812.Ex.0C name	[INT-E 0x0C]
2813.Ex.0D name	[INT-E 0x0D]
2814.Ex.0E name	[INT-E 0x0E]
2815.Ex.0F name	[INT-O 0x0F]
29.Autolight	
290.Autolight 0	
291.Autolight 1	
292.Autolight 2	
293.Autolight 3	
210.ClockFormat	
2100.Clock 0	 [dd mmm, hh:mm:ss]
2101.Clock 1	 [dd mmm, hh:mm:ss]
2102.Clock 2	 [dd mmm, hh:mm:ss]
2013.Clock 3	 [dd mmm, hh:mm:ss]

211.Alarms

2110.Alarms 0

3 wrng codes al.		Panic alarm	
Medical alarm		Silent panic	
Fire alarm			

2111.Alarms 1

3 wrng codes al.		Panic alarm	
Medical alarm		Silent panic	
Fire alarm			

2112.Alarms 2

3 wrng codes al.		Panic alarm	
Medical alarm		Silent panic	
Fire alarm			

2113.Alarms 3

3 wrng codes al.		Panic alarm	
Medical alarm		Silent panic	
Fire alarm			

212.Options

2120.Kpd.0 opts

Show part.1	 [✓]	Quick control	
Show part.2	 [✓]	Troubles review	
Quickarm part.1		Chime on/off	
Quickarm part.2		Disp.mode change	 [✓]
Show code enter.	 [✓]		

2121.Kpd.1 opts

Show part.1	 [✓]	Quick control	
Show part.2	 [✓]	Troubles review	
Quickarm part.1		Chime on/off	
Quickarm part.2		Disp.mode change	 [✓]
Show code enter.	 [✓]		

2122.Kpd.2 opts

Show part.1	 [✓]	Quick control	
Show part.2	 [✓]	Troubles review	
Quickarm part.1		Chime on/off	
Quickarm part.2		Disp.mode change	 [✓]
Show code enter.	 [✓]		

2123.Kpd.3 opts

Show part.1	 [✓]	Quick control	
Show part.2	 [✓]	Troubles review	
Quickarm part.1		Chime on/off	
Quickarm part.2		Disp.mode change	 [✓]
Show code enter.	 [✓]		

213.Wake up

2130.Wake up k0			
2131.Wake up k1			
2132.Wake up k2			
2133.Wake up k3			

218.Connect msg	[Connecting...]
3.Zones	
31.EOL	
311.Zn.1 EOL	
312.Zn.2 EOL	
313.Zn.3 EOL	
314.Zn.4 EOL	
315.Zn.5 EOL	
316.Zn.6 EOL	
317.Zn.7 EOL	
318.Zn.8 EOL	
319.Zn.9 EOL	
3110.Zn.10 EOL	
3111.Zn.11 EOL	
3112.Zn.12 EOL	
3113.Zn.13 EOL	
3114.Zn.14 EOL	
3115.Zn.15 EOL	
3116.Zn.16 EOL	
3117.Zn.17 EOL	
3118.Zn.18 EOL	
3119.Zn.19 EOL	
3120.Zn.20 EOL	
3121.Zn.21 EOL	
3122.Zn.22 EOL	
3123.Zn.23 EOL	
3124.Zn.24 EOL	
3125.Zn.25 EOL	
3126.Zn.26 EOL	
3127.Zn.27 EOL	
3128.Zn.28 EOL	
3129.Zn.29 EOL	
3130.Zn.30 EOL	
3131.Zn.31 EOL	
3132.Zn.32 EOL	
32.Sensitivity	
321.Zn.1 sens.	 [320 ms]
322.Zn.2 sens.	 [320 ms]
323.Zn.3 sens.	 [320 ms]
324.Zn.4 sens.	 [320 ms]
325.Zn.5 sens.	 [320 ms]
326.Zn.6 sens.	 [320 ms]
327.Zn.7 sens.	 [320 ms]
328.Zn.8 sens.	 [320 ms]
329.Zn.9 sens.	 [320 ms]
3210.Zn.10 sens	 [320 ms]
3211.Zn.11 sens	 [320 ms]

3212.Zn.12 sens	[320 ms]
3213.Zn.13 sens	[320 ms]
3214.Zn.14 sens	[320 ms]
3215.Zn.15 sens	[320 ms]
3216.Zn.16 sens	[320 ms]
3217.Zn.17 sens	[320 ms]
3218.Zn.18 sens	[320 ms]
3219.Zn.19 sens	[320 ms]
3220.Zn.20 sens	[320 ms]
3221.Zn.21 sens	[320 ms]
3222.Zn.22 sens	[320 ms]
3223.Zn.23 sens	[320 ms]
3224.Zn.24 sens	[320 ms]
3225.Zn.25 sens	[320 ms]
3226.Zn.26 sens	[320 ms]
3227.Zn.27 sens	[320 ms]
3228.Zn.28 sens	[320 ms]
3229.Zn.29 sens	[320 ms]
3230.Zn.30 sens	[320 ms]
3231.Zn.31 sens	[320 ms]
3232.Zn.32 sens	[320 ms]
33.Type	
331.Zn.1 type	[0.Entry/Exit]
332.Zn.2 type	[3.Instant]
333.Zn.3 type	[3.Instant]
334.Zn.4 type	[3.Instant]
335.Zn.5 type	[3.Instant]
336.Zn.6 type	[3.Instant]
337.Zn.7 type	[3.Instant]
338.Zn.8 type	[6.24h tamper]
339.Zn.9 type	[3.Instant]
3310.Zn.10 type	[3.Instant]
3311.Zn.11 type	[3.Instant]
3312.Zn.12 type	[3.Instant]
3313.Zn.13 type	[3.Instant]
3314.Zn.14 type	[3.Instant]
3315.Zn.15 type	[3.Instant]
3316.Zn.16 type	[3.Instant]
3317.Zn.17 type	[3.Instant]
3318.Zn.18 type	[3.Instant]
3319.Zn.19 type	[3.Instant]
3320.Zn.20 type	[3.Instant]
3321.Zn.21 type	[3.Instant]
3322.Zn.22 type	[3.Instant]
3323.Zn.23 type	[3.Instant]
3324.Zn.24 type	[3.Instant]
3325.Zn.25 type	[3.Instant]

3326.Zn.26 type	[3.Instant]
3327.Zn.27 type	[3.Instant]
3328.Zn.28 type	[3.Instant]
3329.Zn.29 type	[3.Instant]
3330.Zn.30 type	[3.Instant]
3331.Zn.31 type	[3.Instant]
3332.Zn.32 type	[3.Instant]
34.Entry delay	
341.Zn.1 entry	[30 s]
342.Zn.2 entry	
343.Zn.3 entry	
344.Zn.4 entry	
345.Zn.5 entry	
346.Zn.6 entry	
347.Zn.7 entry	
348.Zn.8 entry	
349.Zn.9 entry	
3410.Z.10 entry	
3411.Z.11 entry	
3412.Z.12 entry	
3413.Z.13 entry	
3414.Z.14 entry	
3415.Z.15 entry	
3416.Z.16 entry	
3417.Z.17 entry	
3418.Z.18 entry	
3419.Z.19 entry	
3420.Z.20 entry	
3421.Z.21 entry	
3422.Z.22 entry	
3423.Z.23 entry	
3424.Z.24 entry	
3425.Z.25 entry	
3426.Z.26 entry	
3427.Z.27 entry	
3428.Z.28 entry	
3429.Z.29 entry	
3430.Z.30 entry	
3431.Z.31 entry	
3432.Z.32 entry	
35.Trouble code	
351.Zn.1 trbl.	
352.Zn.2 trbl.	
353.Zn.3 trbl.	
354.Zn.4 trbl.	
355.Zn.5 trbl.	
356.Zn.6 trbl.	

357.Zn.7 trbl.	
358.Zn.8 trbl.	
359.Zn.9 trbl.	
3510.Z.10 trbl.	
3511.Z.11 trbl.	
3512.Z.12 trbl.	
3513.Z.13 trbl.	
3514.Z.14 trbl.	
3515.Z.15 trbl.	
3516.Z.16 trbl.	
3517.Z.17 trbl.	
3518.Z.18 trbl.	
3519.Z.19 trbl.	
3520.Z.20 trbl.	
3521.Z.21 trbl.	
3522.Z.22 trbl.	
3523.Z.23 trbl.	
3524.Z.24 trbl.	
3525.Z.25 trbl.	
3526.Z.26 trbl.	
3527.Z.27 trbl.	
3528.Z.28 trbl.	
3529.Z.29 trbl.	
3530.Z.30 trbl.	
3531.Z.31 trbl.	
3532.Z.32 trbl.	

36.Options

361.P.1 zones

Zone 1	 [✓]	Zone 17	 [✓]
Zone 2	 [✓]	Zone 18	 [✓]
Zone 3	 [✓]	Zone 19	 [✓]
Zone 4	 [✓]	Zone 20	 [✓]
Zone 5	 [✓]	Zone 21	 [✓]
Zone 6	 [✓]	Zone 22	 [✓]
Zone 7	 [✓]	Zone 23	 [✓]
Zone 8	 [✓]	Zone 24	 [✓]
Zone 9	 [✓]	Zone 25	 [✓]
Zone 10	 [✓]	Zone 26	 [✓]
Zone 11	 [✓]	Zone 27	 [✓]
Zone 12	 [✓]	Zone 28	 [✓]
Zone 13	 [✓]	Zone 29	 [✓]
Zone 14	 [✓]	Zone 30	 [✓]
Zone 15	 [✓]	Zone 31	 [✓]
Zone 16	 [✓]	Zone 32	 [✓]

362.P.2 zones

Zone 1		Zone 17	
Zone 2		Zone 18	

Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
363.Night act.			
Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
364.Day active			
Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	

Zone 16		Zone 32	
365.Act.OnePart			
Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
366.Priority			
Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
367.3 alarms			
Zone 1	 [✓]	Zone 17	 [✓]
Zone 2	 [✓]	Zone 18	 [✓]
Zone 3	 [✓]	Zone 19	 [✓]
Zone 4	 [✓]	Zone 20	 [✓]
Zone 5	 [✓]	Zone 21	 [✓]
Zone 6	 [✓]	Zone 22	 [✓]
Zone 7	 [✓]	Zone 23	 [✓]
Zone 8	 [✓]	Zone 24	 [✓]
Zone 9	 [✓]	Zone 25	 [✓]
Zone 10	 [✓]	Zone 26	 [✓]
Zone 11	 [✓]	Zone 27	 [✓]

Zone 12	[✓]	Zone 28	[✓]
Zone 13	[✓]	Zone 29	[✓]
Zone 14	[✓]	Zone 30	[✓]
Zone 15	[✓]	Zone 31	[✓]
Zone 16	[✓]	Zone 32	[✓]
368.Bps.disable			
Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
369.Shnt.disarm			
Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
370.Viol.event			
Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	

Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
371.Rest.event			
Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
372.Alarm clear			
Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
38.Names			
381.Zone 1		[Zone 1]	
382.Zone 2		[Zone 2]	
383.Zone 3		[Zone 3]	

384.Zone 4	 [Zone 4]
385.Zone 5	 [Zone 5]
386.Zone 6	 [Zone 6]
387.Zone 7	 [Zone 7]
388.Zone 8	 [Zone 8]
389.Zone 9	 [Zone 9]
3810.Zone 10	 [Zone 10]
3811.Zone 11	 [Zone 11]
3812.Zone 12	 [Zone 12]
3813.Zone 13	 [Zone 13]
3814.Zone 14	 [Zone 14]
3815.Zone 15	 [Zone 15]
3816.Zone 16	 [Zone 16]
3817.Zone 17	 [Zone 17]
3818.Zone 18	 [Zone 18]
3819.Zone 19	 [Zone 19]
3820.Zone 20	 [Zone 20]
3821.Zone 21	 [Zone 21]
3822.Zone 22	 [Zone 22]
3823.Zone 23	 [Zone 23]
3824.Zone 24	 [Zone 24]
3825.Zone 25	 [Zone 25]
3826.Zone 26	 [Zone 26]
3827.Zone 27	 [Zone 27]
3828.Zone 28	 [Zone 28]
3829.Zone 29	 [Zone 29]
3830.Zone 30	 [Zone 30]
3831.Zone 31	 [Zone 31]
3832.Zone 32	 [Zone 32]
39.Arm mode	
391.Zn.1 arm	 [Arm (full)]
392.Zn.2 arm	 [Arm (full)]
393.Zn.3 arm	 [Arm (full)]
394.Zn.4 arm	 [Arm (full)]
395.Zn.5 arm	 [Arm (full)]
396.Zn.6 arm	 [Arm (full)]
397.Zn.7 arm	 [Arm (full)]
398.Zn.8 arm	 [Arm (full)]
399.Zn.9 arm	 [Arm (full)]
3910.Zn.10 arm	 [Arm (full)]
3911.Zn.11 arm	 [Arm (full)]
3912.Zn.12 arm	 [Arm (full)]
3913.Zn.13 arm	 [Arm (full)]
3914.Zn.14 arm	 [Arm (full)]
3915.Zn.15 arm	 [Arm (full)]
3916.Zn.16 arm	 [Arm (full)]
3917.Zn.17 arm	 [Arm (full)]

3918.Zn.18 arm	 [Arm (full)]
3919.Zn.19 arm	 [Arm (full)]
3920.Zn.20 arm	 [Arm (full)]
3921.Zn.21 arm	 [Arm (full)]
3922.Zn.22 arm	 [Arm (full)]
3923.Zn.23 arm	 [Arm (full)]
3924.Zn.24 arm	 [Arm (full)]
3925.Zn.25 arm	 [Arm (full)]
3926.Zn.26 arm	 [Arm (full)]
3927.Zn.27 arm	 [Arm (full)]
3928.Zn.28 arm	 [Arm (full)]
3929.Zn.29 arm	 [Arm (full)]
3930.Zn.30 arm	 [Arm (full)]
3931.Zn.31 arm	 [Arm (full)]
3932.Zn.32 arm	 [Arm (full)]

4.Outputs

41.Function

411.Function 1	[1.External siren]
412.Function 2	[1.External siren]
413.Function 3	
414.Function 4	
415.Function 5	
416.Function 6	
417.Function 7	
418.Function 8	
419.Function 9	
4110.Out.10 fun	
4111.Out.11 fun	
4112.Out.12 fun	
4113.Out.13 fun	
4114.Out.14 fun	
4115.Out.15 fun	
4116.Out.16 fun	

42.Duration

421.Out.1 dur.	 [5 min]
422.Out.2 dur.	
423.Out.3 dur.	
424.Out.4 dur.	
425.Out.5 dur.	
426.Out.6 dur.	
427.Out.7 dur.	
428.Out.8 dur.	
429.Out.9 dur.	
4210.Out.10 dur	
4211.Out.11 dur	
4212.Out.12 dur	
4213.Out.13 dur	

4214.Out.14 dur	
4215.Out.15 dur	
4216.Out.16 dur	

43.Zones

431.Out.1 zones

Zone 1	[✓]	Zone 17	[✓]
Zone 2	[✓]	Zone 18	[✓]
Zone 3	[✓]	Zone 19	[✓]
Zone 4	[✓]	Zone 20	[✓]
Zone 5	[✓]	Zone 21	[✓]
Zone 6	[✓]	Zone 22	[✓]
Zone 7	[✓]	Zone 23	[✓]
Zone 8	[✓]	Zone 24	[✓]
Zone 9	[✓]	Zone 25	[✓]
Zone 10	[✓]	Zone 26	[✓]
Zone 11	[✓]	Zone 27	[✓]
Zone 12	[✓]	Zone 28	[✓]
Zone 13	[✓]	Zone 29	[✓]
Zone 14	[✓]	Zone 30	[✓]
Zone 15	[✓]	Zone 31	[✓]
Zone 16	[✓]	Zone 32	[✓]

432.Out.2 zones

Zone 1	[✓]	Zone 17	[✓]
Zone 2	[✓]	Zone 18	[✓]
Zone 3	[✓]	Zone 19	[✓]
Zone 4	[✓]	Zone 20	[✓]
Zone 5	[✓]	Zone 21	[✓]
Zone 6	[✓]	Zone 22	[✓]
Zone 7	[✓]	Zone 23	[✓]
Zone 8	[✓]	Zone 24	[✓]
Zone 9	[✓]	Zone 25	[✓]
Zone 10	[✓]	Zone 26	[✓]
Zone 11	[✓]	Zone 27	[✓]
Zone 12	[✓]	Zone 28	[✓]
Zone 13	[✓]	Zone 29	[✓]
Zone 14	[✓]	Zone 30	[✓]
Zone 15	[✓]	Zone 31	[✓]
Zone 16	[✓]	Zone 32	[✓]

433.Out.3 zones

Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	

Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
434.Out.4 zones			
Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
435.Out.5 zones			
Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
436.Out.6 zones			
Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	

20	PERFECTA LTE		SATEL	
	Zone 5		Zone 21	
	Zone 6		Zone 22	
	Zone 7		Zone 23	
	Zone 8		Zone 24	
	Zone 9		Zone 25	
	Zone 10		Zone 26	
	Zone 11		Zone 27	
	Zone 12		Zone 28	
	Zone 13		Zone 29	
	Zone 14		Zone 30	
	Zone 15		Zone 31	
	Zone 16		Zone 32	
437.Out.7 zones				
	Zone 1		Zone 17	
	Zone 2		Zone 18	
	Zone 3		Zone 19	
	Zone 4		Zone 20	
	Zone 5		Zone 21	
	Zone 6		Zone 22	
	Zone 7		Zone 23	
	Zone 8		Zone 24	
	Zone 9		Zone 25	
	Zone 10		Zone 26	
	Zone 11		Zone 27	
	Zone 12		Zone 28	
	Zone 13		Zone 29	
	Zone 14		Zone 30	
	Zone 15		Zone 31	
	Zone 16		Zone 32	
438.Out.8 zones				
	Zone 1		Zone 17	
	Zone 2		Zone 18	
	Zone 3		Zone 19	
	Zone 4		Zone 20	
	Zone 5		Zone 21	
	Zone 6		Zone 22	
	Zone 7		Zone 23	
	Zone 8		Zone 24	
	Zone 9		Zone 25	
	Zone 10		Zone 26	
	Zone 11		Zone 27	
	Zone 12		Zone 28	
	Zone 13		Zone 29	
	Zone 14		Zone 30	
	Zone 15		Zone 31	
	Zone 16		Zone 32	

439.Out.9 zones

Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	

4310.O.10 zones

Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	

4311.O.11 zones

Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	

22	PERFECTA LTE		SATEL	
	Zone 13		Zone 29	
	Zone 14		Zone 30	
	Zone 15		Zone 31	
	Zone 16		Zone 32	
4312.O.12 zones				
	Zone 1		Zone 17	
	Zone 2		Zone 18	
	Zone 3		Zone 19	
	Zone 4		Zone 20	
	Zone 5		Zone 21	
	Zone 6		Zone 22	
	Zone 7		Zone 23	
	Zone 8		Zone 24	
	Zone 9		Zone 25	
	Zone 10		Zone 26	
	Zone 11		Zone 27	
	Zone 12		Zone 28	
	Zone 13		Zone 29	
	Zone 14		Zone 30	
	Zone 15		Zone 31	
	Zone 16		Zone 32	
4313.O.13 zones				
	Zone 1		Zone 17	
	Zone 2		Zone 18	
	Zone 3		Zone 19	
	Zone 4		Zone 20	
	Zone 5		Zone 21	
	Zone 6		Zone 22	
	Zone 7		Zone 23	
	Zone 8		Zone 24	
	Zone 9		Zone 25	
	Zone 10		Zone 26	
	Zone 11		Zone 27	
	Zone 12		Zone 28	
	Zone 13		Zone 29	
	Zone 14		Zone 30	
	Zone 15		Zone 31	
	Zone 16		Zone 32	
4314.O.14 zones				
	Zone 1		Zone 17	
	Zone 2		Zone 18	
	Zone 3		Zone 19	
	Zone 4		Zone 20	
	Zone 5		Zone 21	
	Zone 6		Zone 22	
	Zone 7		Zone 23	
	Zone 8		Zone 24	

Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
4315.O.15 zones			
Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
4316.O.16 zones			
Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
44.Timers			
441.O.1 timers			
Timer 1		Timer 5	
Timer 2		Timer 6	
Timer 3		Timer 7	

Timer 4		Timer 8	
442.O.2 timers			
Timer 1		Timer 5	
Timer 2		Timer 6	
Timer 3		Timer 7	
Timer 4		Timer 8	
443.O.3 timers			
Timer 1		Timer 5	
Timer 2		Timer 6	
Timer 3		Timer 7	
Timer 4		Timer 8	
444.O.4 timers			
Timer 1		Timer 5	
Timer 2		Timer 6	
Timer 3		Timer 7	
Timer 4		Timer 8	
445.O.5 timers			
Timer 1		Timer 5	
Timer 2		Timer 6	
Timer 3		Timer 7	
Timer 4		Timer 8	
446.O.6 timers			
Timer 1		Timer 5	
Timer 2		Timer 6	
Timer 3		Timer 7	
Timer 4		Timer 8	
447.O.7 timers			
Timer 1		Timer 5	
Timer 2		Timer 6	
Timer 3		Timer 7	
Timer 4		Timer 8	
448.O.8 timers			
Timer 1		Timer 5	
Timer 2		Timer 6	
Timer 3		Timer 7	
Timer 4		Timer 8	
449.O.9 timers			
Timer 1		Timer 5	
Timer 2		Timer 6	
Timer 3		Timer 7	
Timer 4		Timer 8	
4410.O10 timers			
Timer 1		Timer 5	
Timer 2		Timer 6	
Timer 3		Timer 7	
Timer 4		Timer 8	

4411.O11 timers			
Timer 1		Timer 5	
Timer 2		Timer 6	
Timer 3		Timer 7	
Timer 4		Timer 8	
4412.O12 timers			
Timer 1		Timer 5	
Timer 2		Timer 6	
Timer 3		Timer 7	
Timer 4		Timer 8	
4413.O13 timers			
Timer 1		Timer 5	
Timer 2		Timer 6	
Timer 3		Timer 7	
Timer 4		Timer 8	
4414.O14 timers			
Timer 1		Timer 5	
Timer 2		Timer 6	
Timer 3		Timer 7	
Timer 4		Timer 8	
4415.O15 timers			
Timer 1		Timer 5	
Timer 2		Timer 6	
Timer 3		Timer 7	
Timer 4		Timer 8	
4416.O16 timers			
Timer 1		Timer 5	
Timer 2		Timer 6	
Timer 3		Timer 7	
Timer 4		Timer 8	
45.Options			
451.P.1 outputs			
Output 1	 [✓]	Output 9	 [✓]
Output 2	 [✓]	Output 10	 [✓]
Output 3	 [✓]	Output 11	 [✓]
Output 4	 [✓]	Output 12	 [✓]
Output 5	 [✓]	Output 13	 [✓]
Output 6	 [✓]	Output 14	 [✓]
Output 7	 [✓]	Output 15	 [✓]
Output 8	 [✓]	Output 16	 [✓]
452.P.2 outputs			
Output 1	 [✓]	Output 9	 [✓]
Output 2	 [✓]	Output 10	 [✓]
Output 3	 [✓]	Output 11	 [✓]
Output 4	 [✓]	Output 12	 [✓]
Output 5	 [✓]	Output 13	 [✓]
Output 6	 [✓]	Output 14	 [✓]

26	PERFECTA LTE	SATEL	
Output 7	[✓]	Output 15	[✓]
Output 8	[✓]	Output 16	[✓]
453.Polarity(+)			
Output 1	[✓]	Output 7	[✓]
Output 2	[✓]	Output 8	[✓]
Output 3	[✓]	Output 9	[✓]
Output 4	[✓]	Output 10	[✓]
Output 5	[✓]	Output 11	[✓]
Output 6	[✓]	Output 12	[✓]
454.Pulsed			
Output 1		Output 7	
Output 2		Output 8	
Output 3		Output 9	
Output 4		Output 10	
Output 5		Output 11	
Output 6		Output 12	
455.Arm/Dis/Clr			
Output 1	[✓]	Output 9	[✓]
Output 2	[✓]	Output 10	[✓]
Output 3	[✓]	Output 11	[✓]
Output 4	[✓]	Output 12	[✓]
Output 5	[✓]	Output 13	[✓]
Output 6	[✓]	Output 14	[✓]
Output 7	[✓]	Output 15	[✓]
Output 8	[✓]	Output 16	[✓]
46.Quick ctrl.			
461. 1# / 1*			
462. 2# / 2*			
463. 3# / 3*			
464. 4# / 4*			
465. 5# / 5*			
466. 6# / 6*			
467. 7# / 7*			
468. 8# / 8*			
469. 9# / 9*			
460. 0# / 0*			
48.Nazwy			
481.Output 1			[Output 1]
482.Output 2			[Output 2]
483.Output 3			[Output 3]
484.Output 4			[Output 4]
485.Output 5			[Output 5]
486.Output 6			[Output 6]
487.Output 7			[Output 7]
488.Output 8			[Output 8]
489.Output 9			[Output 9]
4810.Output 10			[Output 10]

4811.Output 11	 [Output 11]
4812.Output 12	 [Output 12]
4813.Output 13	 [Output 13]
4814.Output 14	 [Output 14]
4815.Output 15	 [Output 15]
4816.Output 16	 [Output 16]

5.Timers

51.Settings

511.Monday

5111.Timer 1	
5112.Timer 2	
5113.Timer 3	
5114.Timer 4	
5115.Timer 5	
5116.Timer 6	
5117.Timer 7	
5118.Timer 8	

512.Tuesday

5121.Timer 1	
5122.Timer 2	
5123.Timer 3	
5124.Timer 4	
5125.Timer 5	
5126.Timer 6	
5127.Timer 7	
5128.Timer 8	

513.Wednesday

5131.Timer 1	
5132.Timer 2	
5133.Timer 3	
5134.Timer 4	
5135.Timer 5	
5136.Timer 6	
5137.Timer 7	
5138.Timer 8	

514.Thursday

5141.Timer 1	
5142.Timer 2	
5143.Timer 3	
5144.Timer 4	
5145.Timer 5	
5146.Timer 6	
5147.Timer 7	
5148.Timer 8	

515.Friday

5151.Timer 1	
5152.Timer 2	

5153.Timer 3	
5154.Timer 4	
5155.Timer 5	
5156.Timer 6	
5157.Timer 7	
5158.Timer 8	
516.Saturday	
5161.Timer 1	
5162.Timer 2	
5163.Timer 3	
5164.Timer 4	
5165.Timer 5	
5166.Timer 6	
5167.Timer 7	
5168.Timer 8	
517.Sunday	
5171.Timer 1	
5172.Timer 2	
5173.Timer 3	
5174.Timer 4	
5175.Timer 5	
5176.Timer 6	
5177.Timer 7	
5178.Timer 8	
518.Everyday	
5181.Timer 1	
5182.Timer 2	
5183.Timer 3	
5184.Timer 4	
5185.Timer 5	
5186.Timer 6	
5187.Timer 7	
5188.Timer 8	
521.Exept.1	
5211.Timer 1	
5212.Timer 2	
5213.Timer 3	
5214.Timer 4	
5215.Timer 5	
5216.Timer 6	
5217.Timer 7	
5218.Timer 8	
522.Exept.2	
5221.Timer 1	
5222.Timer 2	
5223.Timer 3	
5224.Timer 4	

5225.Timer 5	
5226.Timer 6	
5227.Timer 7	
5228.Timer 8	
523.Exept.3	
5231.Timer 1	
5232.Timer 2	
5233.Timer 3	
5234.Timer 4	
5235.Timer 5	
5236.Timer 6	
5237.Timer 7	
5238.Timer 8	
524.Exept.4	
5241.Timer 1	
5242.Timer 2	
5243.Timer 3	
5244.Timer 4	
5245.Timer 5	
5246.Timer 6	
5247.Timer 7	
5248.Timer 8	
53.From	
531.Exept.1	
5311.Timer 1	
5312.Timer 2	
5313.Timer 3	
5314.Timer 4	
5315.Timer 5	
5316.Timer 6	
5317.Timer 7	
5318.Timer 8	
532.Exept.2	
5321.Timer 1	
5322.Timer 2	
5323.Timer 3	
5324.Timer 4	
5325.Timer 5	
5326.Timer 6	
5327.Timer 7	
5328.Timer 8	
533.Exept.3	
5331.Timer 1	
5332.Timer 2	
5333.Timer 3	
5334.Timer 4	
5335.Timer 5	

5336.Timer 6
5337.Timer 7
5338.Timer 8

534.Exept.4

5341.Timer 1
5342.Timer 2
5343.Timer 3
5344.Timer 4
5345.Timer 5
5346.Timer 6
5347.Timer 7
5348.Timer 8

54.Till

541.Exept.1

5411.Timer 1
5412.Timer 2
5413.Timer 3
5414.Timer 4
5415.Timer 5
5416.Timer 6
5417.Timer 7
5418.Timer 8

542.Exept.2

5421.Timer 1
5422.Timer 2
5423.Timer 3
5424.Timer 4
5425.Timer 5
5426.Timer 6
5427.Timer 7
5428.Timer 8

543.Exept.3

5431.Timer 1
5432.Timer 2
5433.Timer 3
5434.Timer 4
5435.Timer 5
5436.Timer 6
5437.Timer 7
5438.Timer 8

544.Exept.4

5441.Timer 1
5442.Timer 2
5443.Timer 3
5444.Timer 4
5445.Timer 5
5446.Timer 6

5447.Timer 7			
5448.Timer 8			
55.Partition 1			
551.Timer 1			
552.Timer 2			
553.Timer 3			
554.Timer 4			
555.Timer 5			
556.Timer 6			
557.Timer 7			
558.Timer 8			
56.Partition 2			
561.Timer 1			
562.Timer 2			
563.Timer 3			
564.Timer 4			
565.Timer 5			
566.Timer 6			
567.Timer 7			
568.Timer 8			
58.Names			
581.Timer 1		[Timer 1]	
582.Timer 2		[Timer 2]	
583.Timer 3		[Timer 3]	
584.Timer 4		[Timer 4]	
585.Timer 5		[Timer 5]	
586.Timer 6		[Timer 6]	
587.Timer 7		[Timer 7]	
588.Timer 8		[Timer 8]	
59.Active			
Timer 1		Timer 5	
Timer 2		Timer 6	
Timer 3		Timer 7	
Timer 4		Timer 8	
6.GSM			
61.SIM1			
611.Options			
SIM1		Auto MCC/MNC	 [✓]
612.PIN			
613.APN			
614.USR			
615.PWD			
616.DNS			
617.SMS centre			
618.MCC/MNC			

62.SIM2			
621.Options			
SIM2		Auto MCC/MNC	[✓]
622.PIN			
623.APN			
624.USR			
625.PWD			
626.DNS			
627.SMS centre			
628.MCC/MNC			
63.Block SIM1			
64.Restore SIM1			
65.Block SIM2			
66.Restore SIM2			
67.Options			
PERFECTA Soft		NTP server time	
PERFECTA CONTROL		USSD any tel.	
PUSH messages		FW adr.from SMS	
GSM network time			
68.SIM credits			
681.USSDchkSIM1			
682.USSDchkSIM2			
683.USSDtopSIM1			
684.USSDtopSIM2			
685.Min.cr.SIM1			
686.Min.cr.SIM2			
687.hh:mm SIM1			
688.hh:mm SIM2			
7.Monitoring			
71.Options			
Monitoring			
72.Stations			 [MS 1]
73.MS1			
731.Identifiers			
732.SIA prefix			
733.Priority			 [1.GPRS SIM1]
734.Tel.(AUDIO)			
735.Tel.(SMS)			
736.Address			
737.Port			
738.Format			 [CID all]
739.STAM key			
740.GPRS key			
741.SMS format			 [Event=●,↑,■,←,→=]
742.SIA-IP acct			
743.SIA-IP key			
744.SIA-IP test			

745.Options			
UDP		Timestamp SIA-IP	
SIA-IP		SIA-IP encrypt.	
Names in SIA		SIA prefix	
National chars			
746.Suspen.time			[3 min]
747.Repetitions			[3]
748.Interval			[0 s]
75.MS2			
751.Identifiers			
752.SIA prefix			
753.Priority			[1.GPRS SIM1]
754.Tel.(AUDIO)			
755.Tel.(SMS)			
756.Address			
757.Port			
758.Format			[CID all]
759.STAM key			
760.GPRS key			
761.SMS format			[Event=●,↑,■,←,→=]
762.SIA-IP acct			
763.SIA-IP key			
764. SIA-IP test			
765.Options			
UDP		Timestamp SIA-IP	
SIA-IP		SIA-IP encrypt.	
Names in SIA		SIA prefix	
National chars			
766.Suspen.time			
767.Repetitions			[3]
768.Interval			[0 s]
77.Assign 1			
771.Zones			
7711.Alarm			
Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	

Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
7712.Al.restore			
Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
7713.Tamper			
Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
7714.Tamp.rest.			
Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	

Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
7715.Bypass			
Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
7716.Unbypass			
Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
7717.Trouble			
Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	

Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
7718.Trbl.rest.			
Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
7719.BAT low			
Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
77110.BAT ok			
Zone 1		Zone 17	

Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
77111.Conn.lost			
Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
77112.Conn. ok			
Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	

Zone 15		Zone 31	
Zone 16		Zone 32	
772.Partitions			
7721.Arm			
Partition 1		Partition 2	
7722.Disarm			
Partition 1		Partition 2	
7723.Al.clear			
Partition 1		Partition 2	
7724.Arm fail.			
Partition 1		Partition 2	
7725.Kfb.panic			
Partition 1		Partition 2	
7726.Kfb.medic.			
Partition 1		Partition 2	
7727.Kfb.fire			
Partition 1		Partition 2	
773.Expanders			
7731.Restarts			
PRF-LCD 0		INT-E 0x0C	
PRF-LCD 1		INT-E 0x0D	
PRF-LCD 2		INT-E 0x0E	
PRF-LCD 3		INT-O 0x0F	
INT-RX-S 0x07			
7732.Duress			
PRF-LCD 0		PRF-LCD 2	
PRF-LCD 1		PRF-LCD 3	
7733.Panic			
PRF-LCD 0		PRF-LCD 2	
PRF-LCD 1		PRF-LCD 3	
7734.Medical			
PRF-LCD 0		PRF-LCD 2	
PRF-LCD 1		PRF-LCD 3	
7735.Fire			
PRF-LCD 0		PRF-LCD 2	
PRF-LCD 1		PRF-LCD 3	
7736.Tamper			
PRF-LCD 0		INT-E 0x0C	
PRF-LCD 1		INT-E 0x0D	
PRF-LCD 2		INT-E 0x0E	
PRF-LCD 3		INT-O 0x0F	
INT-RX-S 0x07			
7737.Tmp.rest.			
PRF-LCD 0		INT-E 0x0C	
PRF-LCD 1		INT-E 0x0D	
PRF-LCD 2		INT-E 0x0E	
PRF-LCD 3		INT-O 0x0F	

INT-RX-S 0x07			
7738.3wrng.code			
PRF-LCD 0		PRF-LCD 2	
PRF-LCD 1		PRF-LCD 3	
7739.AC trouble			
INT-E 0x0C		INT-E 0x0E	
INT-E 0x0D		INT-O 0x0F	
7740.AC restore			
INT-E 0x0C		INT-E 0x0E	
INT-E 0x0D		INT-O 0x0F	
7741.BAT miss.			
INT-E 0x0C		INT-E 0x0E	
INT-E 0x0D		INT-O 0x0F	
7742.BATm.rest.			
INT-E 0x0C		INT-E 0x0E	
INT-E 0x0D		INT-O 0x0F	
7743.BAT low			
INT-E 0x0C		INT-E 0x0E	
INT-E 0x0D		INT-O 0x0F	
7744.BATl.rest.			
INT-E 0x0C		INT-E 0x0E	
INT-E 0x0D		INT-O 0x0F	
7745.BAT low			
PRF-LCD 0		PRF-LCD 2	
PRF-LCD 1		PRF-LCD 3	
7746.BAT ok			
PRF-LCD 0		PRF-LCD 2	
PRF-LCD 1		PRF-LCD 3	
7747.Conn.lost			
PRF-LCD 0		PRF-LCD 2	
PRF-LCD 1		PRF-LCD 3	
7748.Conn. ok			
PRF-LCD 0		PRF-LCD 2	
PRF-LCD 1		PRF-LCD 3	
774.Syst.events			
PERF-Soft conn.		OUT1 trouble	
SM start		OUT2 trouble	
AC trouble		AUX trouble	
BAT missing		KPD trouble	
BAT low		DTA trouble	
MS1 trouble		GSM trouble	
MS2 trouble		Radio jamming	
RTC setting			
775.Syst.rest.			
PERF-Soft disc.		OUT1 restore	
SM end		OUT2 restore	
AC restore		AUX restore	

40	PERFECTA LTE	SATEL
BAT miss.rest.		KPD restore
BAT low restore		DTA restore
MS1 restore		GSM restore
MS2 restore		Radio jam.rest.
RTC trouble		
776.Others		
PERFECTA restart		Manual test
RAM error		Period test
777.Outputs		
7771.BAT low		
Output 13		Output 15
Output 14		Output 16
7772.BAT ok		
Output 13		Output 15
Output 14		Output 16
7773.Conn.lost		
Output 13		Output 15
Output 14		Output 16
7774.Conn. ok		
Output 13		Output 15
Output 14		Output 16
78.Assign 2		
781.Zones		
7811.Alarm		
Zone 1		Zone 17
Zone 2		Zone 18
Zone 3		Zone 19
Zone 4		Zone 20
Zone 5		Zone 21
Zone 6		Zone 22
Zone 7		Zone 23
Zone 8		Zone 24
Zone 9		Zone 25
Zone 10		Zone 26
Zone 11		Zone 27
Zone 12		Zone 28
Zone 13		Zone 29
Zone 14		Zone 30
Zone 15		Zone 31
Zone 16		Zone 32
7812.Al.restore		
Zone 1		Zone 17
Zone 2		Zone 18
Zone 3		Zone 19
Zone 4		Zone 20
Zone 5		Zone 21
Zone 6		Zone 22

Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
7813.Tamper			
Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
7814.Tamp.rest.			
Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
7815.Bypass			
Zone 1		Zone 17	
Zone 2		Zone 18	

Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
7816.Unbypass			
Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
7817.Trouble			
Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	

Zone 16		Zone 32	
7818.Trbl.rest.			
Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
7819.BAT low			
Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
78110.BAT ok			
Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	

Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
78111.Conn.lost			
Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
78112.Conn. ok			
Zone 1		Zone 17	
Zone 2		Zone 18	
Zone 3		Zone 19	
Zone 4		Zone 20	
Zone 5		Zone 21	
Zone 6		Zone 22	
Zone 7		Zone 23	
Zone 8		Zone 24	
Zone 9		Zone 25	
Zone 10		Zone 26	
Zone 11		Zone 27	
Zone 12		Zone 28	
Zone 13		Zone 29	
Zone 14		Zone 30	
Zone 15		Zone 31	
Zone 16		Zone 32	
782.Partitions			
7821.Arm			
Partition 1		Partition 2	
7822.Disarm			
Partition 1		Partition 2	
7823.Al.clear			
Partition 1		Partition 2	

7824.Arm fail.			
Partition 1		Partition 2	
7825.Kfb.panic			
Partition 1		Partition 2	
7826.Kfb.medic.			
Partition 1		Partition 2	
7827.Kfb.fire			
Partition 1		Partition 2	
783.Expanders			
7831.Restarts			
PRF-LCD 0		INT-E 0x0C	
PRF-LCD 1		INT-E 0x0D	
PRF-LCD 2		INT-E 0x0E	
PRF-LCD 3		INT-O 0x0F	
INT-RX-S 0x07			
7832.Duress			
PRF-LCD 0		PRF-LCD 2	
PRF-LCD 1		PRF-LCD 3	
7833.Panic			
PRF-LCD 0		PRF-LCD 2	
PRF-LCD 1		PRF-LCD 3	
7834.Medical			
PRF-LCD 0		PRF-LCD 2	
PRF-LCD 1		PRF-LCD 3	
7835.Fire			
PRF-LCD 0		PRF-LCD 2	
PRF-LCD 1		PRF-LCD 3	
7836.Tamper			
PRF-LCD 0		INT-E 0x0C	
PRF-LCD 1		INT-E 0x0D	
PRF-LCD 2		INT-E 0x0E	
PRF-LCD 3		INT-O 0x0F	
INT-RX-S 0x07			
7837.Tmp.rest.			
PRF-LCD 0		INT-E 0x0C	
PRF-LCD 1		INT-E 0x0D	
PRF-LCD 2		INT-E 0x0E	
PRF-LCD 3		INT-O 0x0F	
INT-RX-S 0x07			
7838.3wrng.code			
PRF-LCD 0		PRF-LCD 2	
PRF-LCD 1		PRF-LCD 3	
7839.AC trouble			
INT-E 0x0C		INT-E 0x0E	
INT-E 0x0D		INT-O 0x0F	
7840.AC restore			
INT-E 0x0C		INT-E 0x0E	
INT-E 0x0D		INT-O 0x0F	

7841.BAT miss			
INT-E 0x0C		INT-E 0x0E	
INT-E 0x0D		INT-O 0x0F	
7842.BATm.rest.			
INT-E 0x0C		INT-E 0x0E	
INT-E 0x0D		INT-O 0x0F	
7843.BAT low			
INT-E 0x0C		INT-E 0x0E	
INT-E 0x0D		INT-O 0x0F	
7844.BATl.rest.			
INT-E 0x0C		INT-E 0x0E	
INT-E 0x0D		INT-O 0x0F	
7845.BAT low			
PRF-LCD 0		PRF-LCD 2	
PRF-LCD 1		PRF-LCD 3	
7846.BAT ok			
PRF-LCD 0		PRF-LCD 2	
PRF-LCD 1		PRF-LCD 3	
7847.Conn.lost			
PRF-LCD 0		PRF-LCD 2	
PRF-LCD 1		PRF-LCD 3	
7848.Conn. ok			
PRF-LCD 0		PRF-LCD 2	
PRF-LCD 1		PRF-LCD 3	
784.Syst.events			
PERF-Soft conn.		OUT1 trouble	
SM start		OUT2 trouble	
AC trouble		AUX trouble	
BAT missing		KPD trouble	
BAT low		DTA trouble	
MS1 trouble		GSM trouble	
MS2 trouble		Radio jamming	
RTC setting			
785.Syst.rest.			
PERF-Soft disc.		OUT1 restore	
SM end		OUT2 restore	
AC restore		AUX restore	
BAT miss.rest.		KPD restore	
BAT low restore		DTA restore	
MS1 restore		GSM restore	
MS2 restore		Radio jam.rest.	
RTC trouble			
786.Others			
PERFECTA restart		Manual test	
RAM error		Period test	

787.Outputs

7871.BAT low

Output 13		Output 15	
-----------	-------	-----------	-------

Output 14		Output 16	
-----------	-------	-----------	-------

7872.BAT ok

Output 13		Output 15	
-----------	-------	-----------	-------

Output 14		Output 16	
-----------	-------	-----------	-------

7873.Conn.lost

Output 13		Output 15	
-----------	-------	-----------	-------

Output 14		Output 16	
-----------	-------	-----------	-------

7874.Conn. ok

Output 13		Output 15	
-----------	-------	-----------	-------

Output 14		Output 16	
-----------	-------	-----------	-------

79.Test events

791.At	
--------	-------

792.Disarmed	
--------------	-------

793.Armed	
-----------	-------

794.Options	
-------------	-------

Independ.test	
---------------	-------

8.Telephones

81.Numbers

811.Phone 1	
-------------	-------

812.Phone 2	
-------------	-------

813.Phone 3	
-------------	-------

814.Phone 4	
-------------	-------

815.Phone 5	
-------------	-------

816.Phone 6	
-------------	-------

817.Phone 7	
-------------	-------

818.Phone 8	
-------------	-------

82.AUDIO msg.

Phone 1		Phone 5	
---------	-------	---------	-------

Phone 2		Phone 6	
---------	-------	---------	-------

Phone 3		Phone 7	
---------	-------	---------	-------

Phone 4		Phone 8	
---------	-------	---------	-------

83.SMS msg.

Phone 1		Phone 5	
---------	-------	---------	-------

Phone 2		Phone 6	
---------	-------	---------	-------

Phone 3		Phone 7	
---------	-------	---------	-------

Phone 4		Phone 8	
---------	-------	---------	-------

84.Unknown SMS

Phone 1		Phone 5	
---------	-------	---------	-------

Phone 2		Phone 6	
---------	-------	---------	-------

Phone 3		Phone 7	
---------	-------	---------	-------

Phone 4		Phone 8	
---------	-------	---------	-------

85.Listening-in

Phone 1		Phone 5	
---------	-------	---------	-------

Phone 2		Phone 6	
---------	-------	---------	-------

48	PERFECTA LTE	SATEL	
Phone 3		Phone 7	
Phone 4		Phone 8	
86.List.durat.			
87.List.aft.msg			
Phone 1		Phone 5	
Phone 2		Phone 6	
Phone 3		Phone 7	
Phone 4		Phone 8	
88.Names			
881.Phone 1			[Phone 1]
882.Phone 2			[Phone 2]
883.Phone 3			[Phone 3]
884.Phone 4			[Phone 4]
885.Phone 5			[Phone 5]
886.Phone 6			[Phone 6]
887.Phone 7			[Phone 7]
888.Phone 8			[Phone 8]
89.On arm.part.			
Partition 1		Partition 2	
9.AUDIO messag.			
91.Options			
AUDIO messag.		Double v.message	
93.Partition 1			
931.Arm			
932.Disarm			
933.Alarm clear			
934.Arm fail.			
935.Alarm			
936.Tamper			
937.Tamp.rest.			
938.Panic			
939.Medical			
9310.Fire			
9311.Duress			
94.Partition 2			
941.Arm			
942.Disarm			
943.Alarm clear			
944.Arm fail.			
945.Alarm			
946.Tamper			
947.Tamp.rest.			
948.Panic			
949.Medical			
9410.Fire			
9411.Duress			

95.Troubles

951.BAT low	
952.BATl.rest.	
953.AC trbl.	
954.AC rest.	
955.GSM tr.rest	

96.Outputs

961.Output 1	
962.Output 2	
963.Output 3	
964.Output 4	
965.Output 5	
966.Output 6	
967.Output 7	
968.Output 8	
969.Output 9	
9610.Output 10	
9611.Output 11	
9612.Output 12	
9613.Output 13	
9614.Output 14	
9615.Output 15	
9616.Output 16	

10.SMS messagin

100.Options

SMS messaging		Messaging events	
---------------	-------	------------------	-------

101.Phone 1

Partition 1		Bypass	
Partition 2		Troubles	
Alarm		Function	
Arm/Disarm/Clear		System	

102.Phone 2

Partition 1		Bypass	
Partition 2		Troubles	
Alarm		Function	
Arm/Disarm/Clear		System	

103.Phone 3

Partition 1		Bypass	
Partition 2		Troubles	
Alarm		Function	
Arm/Disarm/Clear		System	

104.Phone 4

Partition 1		Bypass	
Partition 2		Troubles	
Alarm		Function	
Arm/Disarm/Clear		System	

105.Phone 5

Partition 1		Bypass	
-------------	-------	--------	-------

50	PERFECTA LTE	SATEL
Partition 2		Troubles
Alarm		Function
Arm/Disarm/Clear		System
106.Phone 6		
Partition 1		Bypass
Partition 2		Troubles
Alarm		Function
Arm/Disarm/Clear		System
107.Phone 7		
Partition 1		Bypass
Partition 2		Troubles
Alarm		Function
Arm/Disarm/Clear		System
108.Phone 8		
Partition 1		Bypass
Partition 2		Troubles
Alarm		Function
Arm/Disarm/Clear		System
11.SMS control		
111.USSD SIM1		
112.USSD SIM2		
113.Chk.credit1		
114.Chk.credit2		
115.PERF.Soft		
116.Download FW		
117.Update FW		
118.SMS control		
1181.SMS 1		
1182.SMS 2		
1183.SMS 3		
1184.SMS 4		
1185.SMS 5		
1186.SMS 6		
1187.SMS 7		
1188.SMS 8		
1189.SMS 9		
11810.SMS 10		
11811.SMS 11		
11812.SMS 12		
11813.SMS 13		
11814.SMS 14		
11815.SMS 15		
11816.SMS 16		
119.SMS funct.		
1191.Funct.1		
1192.Funct.2		
1193.Funct.3		

1194.Funct.4			
1195.Funct.5			
1196.Funct.6			
1197.Funct.7			
1198.Funct.8			
1199.Funct.9			
11910.Funct.10			
11911.Funct.11			
11912.Funct.12			
11913.Funct.13			
11914.Funct.14			
11915.Funct.15			
11916.Funct.16			
1110.Any number			
12.Others			
121.Schedules			
1211.Schedule 1			
Arm	 [✓]	Code change	 [✓]
Disarm	 [✓]	Users edit	 [✓]
Alarm clear	 [✓]	Outputs control	 [✓]
Duress		Tests	 [✓]
Zone inhibit	 [✓]	Service access	
Zone isolate		ID change	
1212.Schedule 2			
Arm	 [✓]	Code change	 [✓]
Disarm	 [✓]	Users edit	
Alarm clear	 [✓]	Outputs control	 [✓]
Duress		Tests	
Zone inhibit		Service access	
Zone isolate		ID change	
1213.Schedule 3			
Arm	 [✓]	Code change	 [✓]
Disarm		Users edit	
Alarm clear		Outputs control	
Duress		Tests	
Zone inhibit		Service access	
Zone isolate		ID change	
1214.Schedule 4			
Arm	 [✓]	Code change	
Disarm	 [✓]	Users edit	
Alarm clear	 [✓]	Outputs control	
Duress	 [✓]	Tests	
Zone inhibit		Service access	
Zone isolate		ID change	
1215.Schedule 5			
Arm	 [✓]	Code change	 [✓]
Disarm	 [✓]	Users edit	 [✓]

Alarm clear	[✓]	Outputs control	[✓]
Duress		Tests	[✓]
Zone inhibit	[✓]	Service access	[✓]
Zone isolate	[✓]	ID change	[✓]
1216.Sch.1 name			[Normal]
1217.Sch.2 name			[Simple]
1218.Sch.3 name			[Arms only]
1219.Sch.4 name			[Duress]
1210.Sch.5 name			[Master]
122.Kfb.funct.			
1221.Button ○			
1222.Button □			
1223.Button ▲			
1224.Button ■			
1225.Button ●			
1226.Button ○+●			
123.Max.AC loss			[1 min]
124.Al.duration			[30 s]
125.Suppr.arm			
126.Options			
Grade2		Trbl.in part.arm	
Troubles memory	[✓]	No SATEL trouble	
3wrng.codes=blk.	[✓]	No jamm. trouble	
No AC=no bcklght	[✓]	Check if ready	[✓]
Restore events	[✓]	Arm ExDly w.trbl	[✓]
Events limitat.	[✓]	Tamper = no arm	
Tmp.on ext.siren	[✓]	BAT low = no arm	
Tmp.on int.siren	[✓]		
127.Radio devs			
1271.Add			
1272.Filter			
1273.Remove			
1274.Out.tamper			
1275.Al.signal.			
1276.Acknowled.			