

Alarm Control Panel

PERFECTA

Firmware Version 1.03

perfecta_lf_en 10/19



LIST OF SERVICE FUNCTIONS

SATEL sp. z o.o.
ul. Budowlanych 66
80-298 Gdańsk
POLAND
tel. +48 58 320 94 00
www.satel.eu

Alarm system

Owner

Address

Phone number

Notes.....

.....

.....

.....

.....

.....

1. Introduction

This document presents the list of functions available in the service mode menu. In the square brackets you will find factory default setting (if the parameter is defined / option enabled).

1.1 Starting the service mode

1. Enter the **service code** (by default: 12345) and press *** #**.
2. User menu appears.
3. Press **P | ▲**.
4. When the **→** cursor shows the SERVICE MODE function, press **# □**.
5. Service mode menu will be displayed (the **→** cursor will show the END SM function).

1.2 Navigating through the menu and running functions

To navigate throughout the menu, you can use the arrow keys or number shortcuts. You can also combine the two methods. The cursor **→** shows the submenu you can enter / function you can run.

1.2.1 Using the arrow keys

1. Using the **X | ▾** and **P | ▲** keys, find the required submenu.
2. Press **● | ▶** or **# □** to open a submenu (use the **◀ | ◁** key to go back to the main menu).
3. Repeat the steps 1 and 2 until the required function is found.
4. Press **● | ▶** or **# □** to run the function.

1.2.2 Using the number shortcuts

Submenus and functions are numbered.

1. Use the number keys to enter the number (use the **◀ | ◁** key to erase the last digit).
2. The menu item designated by this number will be displayed (use the *** #** key to go back to the main menu).
3. Press **● | ▶** or **# □** to open a submenu or run a function.

If the cursor **→** indicates END SM and you want to quickly run a function, enter its number and press **● | ▶** or **# □**. For example, to run the expander identification function, press successively **2_{ABC}** **1** **# □**.

If the cursor **→** indicates an item different from END SM, entering a digit will add this digit at the end of the number by which the item displayed in the menu is designated. New digits are always added at the end of the number displayed (only the END SM function is not numbered). For example, if the cursor **→** indicates a menu item with the 31 (31.EOL) number, pressing **3_{DEF}** **2_{ABC}** in turn will display the 3132 (3132.Zn.32 EOL) item, not the 32 (32.SENSITIVITY) item. To display the 32 (32.SENSITIVITY) item, you should press **X | ▾** (to move the cursor **→** down) or **◀ | ◁** **2_{ABC}** (to erase 1 and add 2).

If you remember the submenu/function number and you want to avoid mistakes, press *** #** before entering the number.

1.3 Data editing

The editing method depends on the type of data. Having completed the editing, press **#** to save the changes. If you want to exit the function without saving the changes, press *****.

1.3.1 Selection from the single-choice list

In the lower line of the display, the currently selected item is presented. You can scroll the list using the **X|V** and **P|A** keys.

1.3.2 Selection from the multiple-choice list

In the lower line of the display, one of the items you can choose from is presented. You can scroll the list using the **X|V** and **P|A** keys. The following symbol is situated in the upper right corner of the display:

- ☒** – displayed item is selected / option is enabled,
- displayed item is not selected / option is disabled.

Press any number key to change the currently shown symbol for another one.

If you want to see the status of all items (these can be e.g. zones, outputs, options, etc.), press **☀|▶** or **🌙|◀**. The numbers around the display allow the items to be identified. Use the **☀|▶** and **🌙|◀** keys to move the cursor. After hovering the cursor over the selected item, you can change its status by pressing any number key. If you want to restore the previous way of presentation of the list, press **X|V** or **P|A**.

1.3.3 Entering decimal values

To enter digits, use the number keys. Use the **☀|▶** and **🌙|◀** keys to move the cursor. In some functions, the **P|A** key deletes the character on the left side of the cursor.

1.3.4 Entering hexadecimal values

To enter digits, use the number keys. To enter the A, B and C characters, use the **2_{ABC}** key, and to enter D, E and F, use the **3_{DEF}** key (keep pressing the key until the required character appears). Use the **☀|▶** and **🌙|◀** keys to move the cursor. The **P|A** key deletes the character on the left side of the cursor.

1.3.5 Programming telephone numbers

To enter digits, use the number keys. To enter the +, *, # characters, use the **0₀** key (keep pressing the key until the required character appears). Use the **☀|▶** and **🌙|◀** keys to move the cursor. The **P|A** key deletes the character on the left side of the cursor.

1.3.6 Entering names

The characters that can be entered by using the keys are presented in Table 1. Keep pressing the key until the required character appears. Long press the key to display the digit assigned to it.

Shown on the right side in the upper line of the display is information about the letter case: [ABC] or [abc] (it will be displayed after pressing any key and will be visible for a few seconds after the last keystroke).

Use the **☀|▶** and **🌙|◀** keys to move the cursor. The **P|A** key deletes the character on the left side of the cursor.

Key	Characters available after next keystroke															
1	!	?	'	`	←	"	{	}	\$	%	&	@	\	^		#
2 _{ABC}	a	b	c	2												
3 _{DEF}	d	e	f	3												
4 _{GHI}	g	h	i	4												
5 _{JKL}	j	k	l	5												
6 _{MNO}	m	n	o	6												
7 _{PQRS}	p	q	r	s	7											
8 _{TUV}	t	u	v	.	*	█	H	↑	←	→	↓	8				
9 _{WXYZ}	w	x	y	z	9											
0 ₀	.	,	:	;	+	-	*	/	=	_	<	>	()	[]	0	

Table 1. Characters available when entering names. The upper case letters are available under the same keys (to change the letter case, press **X** **▼**).

1.4 Hiding the service mode

You can hide the service mode by using the 09.HIDE SM function. The control panel will remain in the service mode, but the service mode menu will not be displayed. The function can be useful e.g. when you have to leave the keypad, but you want to prevent unauthorized personnel from getting access to the service menu in the meantime. To get access to the menu again, proceed in the same way as when entering the service mode.

1.5 Exiting the service mode

Keep pressing ***** **◆** until the cursor **→** indicates the SM END function, and then press **#** **□**.

2. Service mode menu

End SM

0.System

 00.Service code [12345]

 01.PERFECTA key

 02.Factory set.

 03.SM config

 SM sounds [✓]

 Block SM

 04.PERFECT.Soft

 041.Address

 042.Port

 05.Remot.update

 051.Address

 052.Port

 06.Time

 061.DST

 062.Summer from

 063.Winter from

 064.Timezone

 065.RTC adjust.

 09.Hide SM

1.Partitions

 13.Exit delay

 131.Exit del.p1 [30 s]

 132.Exit del.ps2 [30 s]

 14.Warn.delay

 141.Warn.del.p1 [30 s]

 142.Warn.del.p2 [30 s]

 15.Verif.delay

 151.Verf.del.p1

 152.Verf.del.p2

 16.Options

 161.P.1 options

 Infinit.ex.delay Entry del. night [✓]

 Fin. exit delay Entry del. day [✓]

 162.P.2 options

 Infinit.ex.delay Entry del. night [✓]

 Fin. exit delay Entry del. day [✓]

 18.Names

 181.Partition 1 [Partition 1]

 182.Partition 2 [Partition 2]

2.Expanders

 20.Kpd.address.

 21.Identificat.

 22.Partitions

220.Kpd.0 part.	[Partition 1]
221.Kpd.1 part.	[Partition 1]
222.Kpd.2 part.	[Partition 1]
223.Kpd.3 part.	[Partition 1]
227.Ex.07 part	[Partition 1]
2212.Ex.0C part	[Partition 1]
2213.Ex.0D part	[Partition 1]
2214.Ex.0E part	[Partition 1]
2215.Ex.0F part	[Partition 1]
23.Max.AC loss		
2312.AC.0C loss	[1 min]
2313.AC.0D loss	[1 min]
2314.AC.0E loss	[1 min]
2315.AC.0F loss	[1 min]
24.Chime		
240.Kpd.0 chime	
241.Kpd.1 chime	
242.Kpd.2 chime	
243.Kpd.3 chime	
25.Volume		
251.Keys		
2510.Keys 0	[25%]
2511.Keys 1	[25%]
2512.Keys 2	[25%]
2513.Keys 3	[25%]
252.Chime		
2520.Chime 0	[100%]
2521.Chime 1	[100%]
2522.Chime 2	[100%]
2523.Chime 3	[100%]
253.Entry delay		
2530.Entry 0	[100%]
2531.Entry 1	[100%]
2532.Entry 2	[100%]
2533.Entry 3	[100%]
254.Exit delay		
2540.Exit 0	[25%]
2541.Exit 1	[25%]
2542.Exit 2	[25%]
2543.Exit 3	[25%]
255.Fire alarm		
2550.Fire 0	[100%]
2551.Fire 1	[100%]
2552.Fire 2	[100%]
2553.Fire 3	[100%]
256.Burg.alarm		
2560.Burg.0	[100%]

2561.Burg.1	[100%]
2562.Burg.2	[100%]
2563.Burg.3	[100%]
257.Warn.alarm	[100%]
2570.Warn.0	[100%]
2571.Warn.1	[100%]
2572.Warn.2	[100%]
2573.Warn.3	[100%]
258.New trouble	[25%]
2580.New trbl.0	[25%]
2581.New trbl.1	[25%]
2582.New trbl.2	[25%]
2583.New trbl.3	[25%]
26.LCDbacklight	[auto 0-50%]
260.LCD bl.0	[auto 0-50%]
261.LCD bl.1	[auto 0-50%]
262.LCD bl.2	[auto 0-50%]
263.LCD bl.3	[auto 0-50%]
27.KEYbacklight	[auto]
270.KEY bl.0	[auto]
271.KEY bl.1	[auto]
272.KEY bl.2	[auto]
273.KEY bl.3	[auto]
28.Names	[PRF-LCD 0]
280.Kpd.0 name	[PRF-LCD 1]
281.Kpd.1 name	[PRF-LCD 2]
282.Kpd.2 name	[PRF-LCD 3]
283.Kpd.3 name	[INT-RX-S 0x07]
287.Ex.07 name	[INT-E 0x0C]
2812.Ex.0C name	[INT-E 0x0D]
2813.Ex.0D name	[INT-E 0x0E]
2814.Ex.0E name	[INT-O 0x0F]
2815.Ex.0F name	[INT-O 0x0F]
29.Autolight	
290.Autolight 0	
291.Autolight 1	
292.Autolight 2	
293.Autolight 3	
210.ClockFormat	
2100.Clock 0	[dd mmm, hh:mm:ss]
2101.Clock 1	[dd mmm, hh:mm:ss]
2102.Clock 2	[dd mmm, hh:mm:ss]
2013.Clock 3	[dd mmm, hh:mm:ss]

211.Altarms			
2110.Altarms 0			
3 wrng codes al.	Panic alarm
Medical alarm	Silent panic
Fire alarm		
2111.Altarms 1			
3 wrng codes al.	Panic alarm
Medical alarm	Silent panic
Fire alarm		
2112.Altarms 2			
3 wrng codes al.	Panic alarm
Medical alarm	Silent panic
Fire alarm		
2113.Altarms 3			
3 wrng codes al.	Panic alarm
Medical alarm	Silent panic
Fire alarm		
212.Options			
2120.Kpd.0 opts			
Show part.1 [✓]	Quick control
Show part.2 [✓]	Troubles review
Quickarm part.1	Chime on/off
Quickarm part.2	Disp.mode change [✓]
Show code enter. [✓]		
2121.Kpd.1 opts			
Show part.1 [✓]	Quick control
Show part.2 [✓]	Troubles review
Quickarm part.1	Chime on/off
Quickarm part.2	Disp.mode change [✓]
Show code enter. [✓]		
2122.Kpd.2 opts			
Show part.1 [✓]	Quick control
Show part.2 [✓]	Troubles review
Quickarm part.1	Chime on/off
Quickarm part.2	Disp.mode change [✓]
Show code enter. [✓]		
2123.Kpd.3 opts			
Show part.1 [✓]	Quick control
Show part.2 [✓]	Troubles review
Quickarm part.1	Chime on/off
Quickarm part.2	Disp.mode change [✓]
Show code enter. [✓]		
213.Wake up			
2130.Wake up k0		
2131.Wake up k1		
2132.Wake up k2		
2133.Wake up k3		

218.Connect msg	[Connecting...]
3.Zones		
31.EOL		
311.Zn.1 EOL	
312.Zn.2 EOL	
313.Zn.3 EOL	
314.Zn.4 EOL	
315.Zn.5 EOL	
316.Zn.6 EOL	
317.Zn.7 EOL	
318.Zn.8 EOL	
319.Zn.9 EOL	
3110.Zn.10 EOL	
3111.Zn.11 EOL	
3112.Zn.12 EOL	
3113.Zn.13 EOL	
3114.Zn.14 EOL	
3115.Zn.15 EOL	
3116.Zn.16 EOL	
3117.Zn.17 EOL	
3118.Zn.18 EOL	
3119.Zn.19 EOL	
3120.Zn.20 EOL	
3121.Zn.21 EOL	
3122.Zn.22 EOL	
3123.Zn.23 EOL	
3124.Zn.24 EOL	
3125.Zn.25 EOL	
3126.Zn.26 EOL	
3127.Zn.27 EOL	
3128.Zn.28 EOL	
3129.Zn.29 EOL	
3130.Zn.30 EOL	
3131.Zn.31 EOL	
3132.Zn.32 EOL	
32.Sensitivity		
321.Zn.1 sens.	[320 ms]
322.Zn.2 sens.	[320 ms]
323.Zn.3 sens.	[320 ms]
324.Zn.4 sens.	[320 ms]
325.Zn.5 sens.	[320 ms]
326.Zn.6 sens.	[320 ms]
327.Zn.7 sens.	[320 ms]
328.Zn.8 sens.	[320 ms]
329.Zn.9 sens.	[320 ms]
3210.Zn.10 sens	[320 ms]
3211.Zn.11 sens	[320 ms]

3212.Zn.12 sens	[320 ms]
3213.Zn.13 sens	[320 ms]
3214.Zn.14 sens	[320 ms]
3215.Zn.15 sens	[320 ms]
3216.Zn.16 sens	[320 ms]
3217.Zn.17 sens	[320 ms]
3218.Zn.18 sens	[320 ms]
3219.Zn.19 sens	[320 ms]
3220.Zn.20 sens	[320 ms]
3221.Zn.21 sens	[320 ms]
3222.Zn.22 sens	[320 ms]
3223.Zn.23 sens	[320 ms]
3224.Zn.24 sens	[320 ms]
3225.Zn.25 sens	[320 ms]
3226.Zn.26 sens	[320 ms]
3227.Zn.27 sens	[320 ms]
3228.Zn.28 sens	[320 ms]
3229.Zn.29 sens	[320 ms]
3230.Zn.30 sens	[320 ms]
3231.Zn.31 sens	[320 ms]
3232.Zn.32 sens	[320 ms]
33.Type		
331.Zn.1 type	[0.Entry/Exit]
332.Zn.2 type	[3.Instant]
333.Zn.3 type	[3.Instant]
334.Zn.4 type	[3.Instant]
335.Zn.5 type	[3.Instant]
336.Zn.6 type	[3.Instant]
337.Zn.7 type	[3.Instant]
338.Zn.8 type	[6.24h tamper]
339.Zn.9 type	[3.Instant]
3310.Zn.10 type	[3.Instant]
3311.Zn.11 type	[3.Instant]
3312.Zn.12 type	[3.Instant]
3313.Zn.13 type	[3.Instant]
3314.Zn.14 type	[3.Instant]
3315.Zn.15 type	[3.Instant]
3316.Zn.16 type	[3.Instant]
3317.Zn.17 type	[3.Instant]
3318.Zn.18 type	[3.Instant]
3319.Zn.19 type	[3.Instant]
3320.Zn.20 type	[3.Instant]
3321.Zn.21 type	[3.Instant]
3322.Zn.22 type	[3.Instant]
3323.Zn.23 type	[3.Instant]
3324.Zn.24 type	[3.Instant]
3325.Zn.25 type	[3.Instant]

3326.Zn.26 type	[3.Instant]
3327.Zn.27 type	[3.Instant]
3328.Zn.28 type	[3.Instant]
3329.Zn.29 type	[3.Instant]
3330.Zn.30 type	[3.Instant]
3331.Zn.31 type	[3.Instant]
3332.Zn.32 type	[3.Instant]
34.Entry delay		
341.Zn.1 entry	[30 s]
342.Zn.2 entry	
343.Zn.3 entry	
344.Zn.4 entry	
345.Zn.5 entry	
346.Zn.6 entry	
347.Zn.7 entry	
348.Zn.8 entry	
349.Zn.9 entry	
3410.Z.10 entry	
3411.Z.11 entry	
3412.Z.12 entry	
3413.Z.13 entry	
3414.Z.14 entry	
3415.Z.15 entry	
3416.Z.16 entry	
3417.Z.17 entry	
3418.Z.18 entry	
3419.Z.19 entry	
3420.Z.20 entry	
3421.Z.21 entry	
3422.Z.22 entry	
3423.Z.23 entry	
3424.Z.24 entry	
3425.Z.25 entry	
3426.Z.26 entry	
3427.Z.27 entry	
3428.Z.28 entry	
3429.Z.29 entry	
3430.Z.30 entry	
3431.Z.31 entry	
3432.Z.32 entry	
35.Trouble code		
351.Zn.1 trbl.	
352.Zn.2 trbl.	
353.Zn.3 trbl.	
354.Zn.4 trbl.	
355.Zn.5 trbl.	
356.Zn.6 trbl.	

357.Zn.7 trbl.
358.Zn.8 trbl.
359.Zn.9 trbl.
3510.Z.10 trbl.
3511.Z.11 trbl.
3512.Z.12 trbl.
3513.Z.13 trbl.
3514.Z.14 trbl.
3515.Z.15 trbl.
3516.Z.16 trbl.
3517.Z.17 trbl.
3518.Z.18 trbl.
3519.Z.19 trbl.
3520.Z.20 trbl.
3521.Z.21 trbl.
3522.Z.22 trbl.
3523.Z.23 trbl.
3524.Z.24 trbl.
3525.Z.25 trbl.
3526.Z.26 trbl.
3527.Z.27 trbl.
3528.Z.28 trbl.
3529.Z.29 trbl.
3530.Z.30 trbl.
3531.Z.31 trbl.
3532.Z.32 trbl.

36.Options

361.P.1 zones

Zone 1 [✓]	Zone 17 [✓]
Zone 2 [✓]	Zone 18 [✓]
Zone 3 [✓]	Zone 19 [✓]
Zone 4 [✓]	Zone 20 [✓]
Zone 5 [✓]	Zone 21 [✓]
Zone 6 [✓]	Zone 22 [✓]
Zone 7 [✓]	Zone 23 [✓]
Zone 8 [✓]	Zone 24 [✓]
Zone 9 [✓]	Zone 25 [✓]
Zone 10 [✓]	Zone 26 [✓]
Zone 11 [✓]	Zone 27 [✓]
Zone 12 [✓]	Zone 28 [✓]
Zone 13 [✓]	Zone 29 [✓]
Zone 14 [✓]	Zone 30 [✓]
Zone 15 [✓]	Zone 31 [✓]
Zone 16 [✓]	Zone 32 [✓]

362.P.2 zones

Zone 1	Zone 17
Zone 2	Zone 18

Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32

363.Night act.

Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32

364.Day active

Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31

Zone 16	Zone 32
365.Act.OnePart			
Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32
366.Priority			
Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32
367.3 alarms			
Zone 1 [✓]	Zone 17 [✓]
Zone 2 [✓]	Zone 18 [✓]
Zone 3 [✓]	Zone 19 [✓]
Zone 4 [✓]	Zone 20 [✓]
Zone 5 [✓]	Zone 21 [✓]
Zone 6 [✓]	Zone 22 [✓]
Zone 7 [✓]	Zone 23 [✓]
Zone 8 [✓]	Zone 24 [✓]
Zone 9 [✓]	Zone 25 [✓]
Zone 10 [✓]	Zone 26 [✓]
Zone 11 [✓]	Zone 27 [✓]

Zone 12[✓]	Zone 28[✓]
Zone 13[✓]	Zone 29[✓]
Zone 14[✓]	Zone 30[✓]
Zone 15[✓]	Zone 31[✓]
Zone 16[✓]	Zone 32[✓]
368.Bps disable			
Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32
369.Shnt.disarm			
Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32
370.Viol.event			
Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23

Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32
371.Rest.event			
Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32
372.Alarm clear			
Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32
38.Names			
381.Zone 1			[Zone 1]
382.Zone 2			[Zone 2]
383.Zone 3			[Zone 3]

384.Zone 4	[Zone 4]
385.Zone 5	[Zone 5]
386.Zone 6	[Zone 6]
387.Zone 7	[Zone 7]
388.Zone 8	[Zone 8]
389.Zone 9	[Zone 9]
3810.Zone 10	[Zone 10]
3811.Zone 11	[Zone 11]
3812.Zone 12	[Zone 12]
3813.Zone 13	[Zone 13]
3814.Zone 14	[Zone 14]
3815.Zone 15	[Zone 15]
3816.Zone 16	[Zone 16]
3817.Zone 17	[Zone 17]
3818.Zone 18	[Zone 18]
3819.Zone 19	[Zone 19]
3820.Zone 20	[Zone 20]
3821.Zone 21	[Zone 21]
3822.Zone 22	[Zone 22]
3823.Zone 23	[Zone 23]
3824.Zone 24	[Zone 24]
3825.Zone 25	[Zone 25]
3826.Zone 26	[Zone 26]
3827.Zone 27	[Zone 27]
3828.Zone 28	[Zone 28]
3829.Zone 29	[Zone 29]
3830.Zone 30	[Zone 30]
3831.Zone 31	[Zone 31]
3832.Zone 32	[Zone 32]
39.Arm mode		
391.Zn.1 arm	[Arm (full)]
392.Zn.2 arm	[Arm (full)]
393.Zn.3 arm	[Arm (full)]
394.Zn.4 arm	[Arm (full)]
395.Zn.5 arm	[Arm (full)]
396.Zn.6 arm	[Arm (full)]
397.Zn.7 arm	[Arm (full)]
398.Zn.8 arm	[Arm (full)]
399.Zn.9 arm	[Arm (full)]
3910.Zn.10 arm	[Arm (full)]
3911.Zn.11 arm	[Arm (full)]
3912.Zn.12 arm	[Arm (full)]
3913.Zn.13 arm	[Arm (full)]
3914.Zn.14 arm	[Arm (full)]
3915.Zn.15 arm	[Arm (full)]
3916.Zn.16 arm	[Arm (full)]
3917.Zn.17 arm	[Arm (full)]

3918.Zn.18 arm	[Arm (full)]
3919.Zn.19 arm	[Arm (full)]
3920.Zn.20 arm	[Arm (full)]
3921.Zn.21 arm	[Arm (full)]
3922.Zn.22 arm	[Arm (full)]
3923.Zn.23 arm	[Arm (full)]
3924.Zn.24 arm	[Arm (full)]
3925.Zn.25 arm	[Arm (full)]
3926.Zn.26 arm	[Arm (full)]
3927.Zn.27 arm	[Arm (full)]
3928.Zn.28 arm	[Arm (full)]
3929.Zn.29 arm	[Arm (full)]
3930.Zn.30 arm	[Arm (full)]
3931.Zn.31 arm	[Arm (full)]
3932.Zn.32 arm	[Arm (full)]

4.Outputs**41.Function**

411.Function 1	[1.External siren]
412.Function 2	[1.External siren]
413.Function 3	
414.Function 4	
415.Function 5	
416.Function 6	
417.Function 7	
418.Function 8	
419.Function 9	
4110.Out.10 fun	
4111.Out.11 fun	
4112.Out.12 fun	
4113.Out.13 fun	
4114.Out.14 fun	
4115.Out.15 fun	
4116.Out.16 fun	

42.Duration

421.Out.1 dur.	[5 min]
422.Out.2 dur.	
423.Out.3 dur.	
424.Out.4 dur.	
425.Out.5 dur.	
426.Out.6 dur.	
427.Out.7 dur.	
428.Out.8 dur.	
429.Out.9 dur.	
4210.Out.10 dur	
4211.Out.11 dur	
4212.Out.12 dur	
4213.Out.13 dur	

4214.Out.14 dur
 4215.Out.15 dur
 4216.Out.16 dur

43.Zones

431.Out.1 zones

Zone 1[✓]	Zone 17[✓]
Zone 2[✓]	Zone 18[✓]
Zone 3[✓]	Zone 19[✓]
Zone 4[✓]	Zone 20[✓]
Zone 5[✓]	Zone 21[✓]
Zone 6[✓]	Zone 22[✓]
Zone 7[✓]	Zone 23[✓]
Zone 8[✓]	Zone 24[✓]
Zone 9[✓]	Zone 25[✓]
Zone 10[✓]	Zone 26[✓]
Zone 11[✓]	Zone 27[✓]
Zone 12[✓]	Zone 28[✓]
Zone 13[✓]	Zone 29[✓]
Zone 14[✓]	Zone 30[✓]
Zone 15[✓]	Zone 31[✓]
Zone 16[✓]	Zone 32[✓]

432.Out.2 zones

Zone 1[✓]	Zone 17[✓]
Zone 2[✓]	Zone 18[✓]
Zone 3[✓]	Zone 19[✓]
Zone 4[✓]	Zone 20[✓]
Zone 5[✓]	Zone 21[✓]
Zone 6[✓]	Zone 22[✓]
Zone 7[✓]	Zone 23[✓]
Zone 8[✓]	Zone 24[✓]
Zone 9[✓]	Zone 25[✓]
Zone 10[✓]	Zone 26[✓]
Zone 11[✓]	Zone 27[✓]
Zone 12[✓]	Zone 28[✓]
Zone 13[✓]	Zone 29[✓]
Zone 14[✓]	Zone 30[✓]
Zone 15[✓]	Zone 31[✓]
Zone 16[✓]	Zone 32[✓]

433.Out.3 zones

Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24

Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32
434.Out.4 zones			
Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32
435.Out.5 zones			
Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32
436.Out.6 zones			
Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20

Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32

437.Out.7 zones

Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32

438.Out.8 zones

Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32

439.Out.9 zones

Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32

4310.O.10 zones

Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32

4311.O.11 zones

Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28

Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32
4312.O.12 zones			
Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32
4313.O.13 zones			
Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32
4314.O.14 zones			
Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24

Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32
4315.O.15 zones			
Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32
4316.O.16 zones			
Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32
44.Timers			
441.O.1 timers			
Timer 1	Timer 5
Timer 2	Timer 6
Timer 3	Timer 7

Timer 4	Timer 8
442.O.2 timers			
Timer 1	Timer 5
Timer 2	Timer 6
Timer 3	Timer 7
Timer 4	Timer 8
443.O.3 timers			
Timer 1	Timer 5
Timer 2	Timer 6
Timer 3	Timer 7
Timer 4	Timer 8
444.O.4 timers			
Timer 1	Timer 5
Timer 2	Timer 6
Timer 3	Timer 7
Timer 4	Timer 8
445.O.5 timers			
Timer 1	Timer 5
Timer 2	Timer 6
Timer 3	Timer 7
Timer 4	Timer 8
446.O.6 timers			
Timer 1	Timer 5
Timer 2	Timer 6
Timer 3	Timer 7
Timer 4	Timer 8
447.O.7 timers			
Timer 1	Timer 5
Timer 2	Timer 6
Timer 3	Timer 7
Timer 4	Timer 8
448.O.8 timers			
Timer 1	Timer 5
Timer 2	Timer 6
Timer 3	Timer 7
Timer 4	Timer 8
449.O.9 timers			
Timer 1	Timer 5
Timer 2	Timer 6
Timer 3	Timer 7
Timer 4	Timer 8
4410.O10 timers			
Timer 1	Timer 5
Timer 2	Timer 6
Timer 3	Timer 7
Timer 4	Timer 8

4411.O11 timers			
Timer 1	Timer 5
Timer 2	Timer 6
Timer 3	Timer 7
Timer 4	Timer 8
4412.O12 timers			
Timer 1	Timer 5
Timer 2	Timer 6
Timer 3	Timer 7
Timer 4	Timer 8
4413.O13 timers			
Timer 1	Timer 5
Timer 2	Timer 6
Timer 3	Timer 7
Timer 4	Timer 8
4414.O14 timers			
Timer 1	Timer 5
Timer 2	Timer 6
Timer 3	Timer 7
Timer 4	Timer 8
4415.O15 timers			
Timer 1	Timer 5
Timer 2	Timer 6
Timer 3	Timer 7
Timer 4	Timer 8
4416.O16 timers			
Timer 1	Timer 5
Timer 2	Timer 6
Timer 3	Timer 7
Timer 4	Timer 8
45.Options			
451.P.1 outputs			
Output 1 [✓]	Output 9 [✓]
Output 2 [✓]	Output 10 [✓]
Output 3 [✓]	Output 11 [✓]
Output 4 [✓]	Output 12 [✓]
Output 5 [✓]	Output 13 [✓]
Output 6 [✓]	Output 14 [✓]
Output 7 [✓]	Output 15 [✓]
Output 8 [✓]	Output 16 [✓]
452.P.2 outputs			
Output 1 [✓]	Output 9 [✓]
Output 2 [✓]	Output 10 [✓]
Output 3 [✓]	Output 11 [✓]
Output 4 [✓]	Output 12 [✓]
Output 5 [✓]	Output 13 [✓]
Output 6 [✓]	Output 14 [✓]

Output 7[✓]	Output 15[✓]
Output 8[✓]	Output 16[✓]
453.Polarity(+)			
Output 1[✓]	Output 7[✓]
Output 2[✓]	Output 8[✓]
Output 3[✓]	Output 9[✓]
Output 4[✓]	Output 10[✓]
Output 5[✓]	Output 11[✓]
Output 6[✓]	Output 12[✓]
454.Pulsed			
Output 1	Output 7
Output 2	Output 8
Output 3	Output 9
Output 4	Output 10
Output 5	Output 11
Output 6	Output 12
455.Arm/Dis/Clr			
Output 1[✓]	Output 9[✓]
Output 2[✓]	Output 10[✓]
Output 3[✓]	Output 11[✓]
Output 4[✓]	Output 12[✓]
Output 5[✓]	Output 13[✓]
Output 6[✓]	Output 14[✓]
Output 7[✓]	Output 15[✓]
Output 8[✓]	Output 16[✓]
46.Quick ctrl.			
461. 1# / 1*		
462. 2# / 2*		
463. 3# / 3*		
464. 4# / 4*		
465. 5# / 5*		
466. 6# / 6*		
467. 7# / 7*		
468. 8# / 8*		
469. 9# / 9*		
460. 0# / 0*		
48.Nazwy			
481.Output 1	[Output 1]	
482.Output 2	[Output 2]	
483.Output 3	[Output 3]	
484.Output 4	[Output 4]	
485.Output 5	[Output 5]	
486.Output 6	[Output 6]	
487.Output 7	[Output 7]	
488.Output 8	[Output 8]	
489.Output 9	[Output 9]	
4810.Output 10	[Output 10]	

4811.Output 11	[Output 11]
4812.Output 12	[Output 12]
4813.Output 13	[Output 13]
4814.Output 14	[Output 14]
4815.Output 15	[Output 15]
4816.Output 16	[Output 16]

5.Timers

51.Settings

511.Monday	
5111.Timer 1	
5112.Timer 2	
5113.Timer 3	
5114.Timer 4	
5115.Timer 5	
5116.Timer 6	
5117.Timer 7	
5118.Timer 8	
512.Tuesday	
5121.Timer 1	
5122.Timer 2	
5123.Timer 3	
5124.Timer 4	
5125.Timer 5	
5126.Timer 6	
5127.Timer 7	
5128.Timer 8	
513.Wednesday	
5131.Timer 1	
5132.Timer 2	
5133.Timer 3	
5134.Timer 4	
5135.Timer 5	
5136.Timer 6	
5137.Timer 7	
5138.Timer 8	
514.Thursday	
5141.Timer 1	
5142.Timer 2	
5143.Timer 3	
5144.Timer 4	
5145.Timer 5	
5146.Timer 6	
5147.Timer 7	
5148.Timer 8	
515.Friday	
5151.Timer 1	
5152.Timer 2	

5153.Timer 3
5154.Timer 4
5155.Timer 5
5156.Timer 6
5157.Timer 7
5158.Timer 8
516.Saturday
5161.Timer 1
5162.Timer 2
5163.Timer 3
5164.Timer 4
5165.Timer 5
5166.Timer 6
5167.Timer 7
5168.Timer 8
517.Sunday
5171.Timer 1
5172.Timer 2
5173.Timer 3
5174.Timer 4
5175.Timer 5
5176.Timer 6
5177.Timer 7
5178.Timer 8
518.Everyday
5181.Timer 1
5182.Timer 2
5183.Timer 3
5184.Timer 4
5185.Timer 5
5186.Timer 6
5187.Timer 7
5188.Timer 8
521.Except.1
5211.Timer 1
5212.Timer 2
5213.Timer 3
5214.Timer 4
5215.Timer 5
5216.Timer 6
5217.Timer 7
5218.Timer 8
522.Except.2
5221.Timer 1
5222.Timer 2
5223.Timer 3
5224.Timer 4

5225.Timer 5
5226.Timer 6
5227.Timer 7
5228.Timer 8
523.Except.3
5231.Timer 1
5232.Timer 2
5233.Timer 3
5234.Timer 4
5235.Timer 5
5236.Timer 6
5237.Timer 7
5238.Timer 8
524.Except.4
5241.Timer 1
5242.Timer 2
5243.Timer 3
5244.Timer 4
5245.Timer 5
5246.Timer 6
5247.Timer 7
5248.Timer 8
53.From	
531.Except.1	
5311.Timer 1
5312.Timer 2
5313.Timer 3
5314.Timer 4
5315.Timer 5
5316.Timer 6
5317.Timer 7
5318.Timer 8
532.Except.2	
5321.Timer 1
5322.Timer 2
5323.Timer 3
5324.Timer 4
5325.Timer 5
5326.Timer 6
5327.Timer 7
5328.Timer 8
533.Except.3	
5331.Timer 1
5332.Timer 2
5333.Timer 3
5334.Timer 4
5335.Timer 5

5336.Timer 6
5337.Timer 7
5338.Timer 8
534.Except.4
5341.Timer 1
5342.Timer 2
5343.Timer 3
5344.Timer 4
5345.Timer 5
5346.Timer 6
5347.Timer 7
5348.Timer 8
54.Till	
541.Except.1	
5411.Timer 1
5412.Timer 2
5413.Timer 3
5414.Timer 4
5415.Timer 5
5416.Timer 6
5417.Timer 7
5418.Timer 8
542.Except.2	
5421.Timer 1
5422.Timer 2
5423.Timer 3
5424.Timer 4
5425.Timer 5
5426.Timer 6
5427.Timer 7
5428.Timer 8
543.Except.3	
5431.Timer 1
5432.Timer 2
5433.Timer 3
5434.Timer 4
5435.Timer 5
5436.Timer 6
5437.Timer 7
5438.Timer 8
544.Except.4	
5441.Timer 1
5442.Timer 2
5443.Timer 3
5444.Timer 4
5445.Timer 5
5446.Timer 6

5447.Timer 7
5448.Timer 8
55.Partition 1	
551.Timer 1
552.Timer 2
553.Timer 3
554.Timer 4
555.Timer 5
556.Timer 6
557.Timer 7
558.Timer 8
56.Partition 2	
561.Timer 1
562.Timer 2
563.Timer 3
564.Timer 4
565.Timer 5
566.Timer 6
567.Timer 7
568.Timer 8
58.Names	
581.Timer 1 [Timer 1]
582.Timer 2 [Timer 2]
583.Timer 3 [Timer 3]
584.Timer 4 [Timer 4]
585.Timer 5 [Timer 5]
586.Timer 6 [Timer 6]
587.Timer 7 [Timer 7]
588.Timer 8 [Timer 8]
59.Active	
Timer 1
Timer 2
Timer 3
Timer 4
Timer 5
Timer 6
Timer 7
Timer 8
6.GSM	
61.SIM1	
611.Options	
SIM1
612.PIN
613.APN
614.USR
615.PWD
616.DNS
617.SMS centre
618.MCC/MNC
Auto MCC/MNC [✓]

62.SIM2			
621.Options			
SIM2	Auto MCC/MNC [✓]
622.PIN			
623.APN			
624.USR			
625.PWD			
626.DNS			
627.SMS centre			
628.MCC/MNC			
63.Block SIM1			
64.Restore SIM1			
65.Block SIM2			
66.Restore SIM2			
67.Options			
PERFECTA Soft	NTP server time
PERFECTA CONTROL	USSD any tel.
PUSH messages	FW adr.from SMS
GSM network time		
68.SIM credits			
681.USSDchkSIM1			
682.USSDchkSIM2			
683.USSDtopSIM1			
684.USSDtopSIM2			
685.Min.cr.SIM1			
686.Min.cr.SIM2			
687.hh:mm SIM1			
688.hh:mm SIM2			
7.Monitoring			
71.Options			
Monitoring			
72.Stations			[MS 1]
73.MS1			
731.Identifiers			
732.SIA prefix			
733.Priority			[1.GPRS SIM1]
734.Tel.(AUDIO)			
735.Tel.(SMS)			
736.Address			
737.Port			
738.Format			[CID all]
739.STAM key			
740.GPRS key			
741.SMS format			[Event=●,↑,■,←,→=]
742.SIA-IP acct			
743.SIA-IP key			
744.SIA-IP test			

745.Options			
UDP	Timestamp SIA-IP
SIA-IP	SIA-IP encrypt.
Names in SIA	SIA prefix
National chars		
746.Suspen.time			[3 min]
75.MS2			
751.Identifiers			
752.SIA prefix			
753.Priority			[1.GPRS SIM1]
754.Tel.(AUDIO)			
755.Tel.(SMS)			
756.Address			
757.Port			
758.Format			[CID all]
759.STAM key			
760.GPRS key			
761.SMS format			[Event=●,↑,■,←,→=]
762.SIA-IP acct			
763.SIA-IP key			
764. SIA-IP test			
765.Options			
UDP	Timestamp SIA-IP
SIA-IP	SIA-IP encrypt.
Names in SIA	SIA prefix
National chars		
766.Suspen.time			
77.Assign 1			
771.Zones			
7711.Alarm			
Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32

7712.Al.restore

Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32

7713.Tamper

Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32

7714.Tamp.rest.

Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28

Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32
7715.Bypass			
Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32
7716.Unbypass			
Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32
7717.Trouble			
Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24

Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32
7718.Trbl.rest.			
Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32
772.Partitions			
7721.Arm			
Partition 1	Partition 2
7722.Disarm			
Partition 1	Partition 2
7723.Al.clear			
Partition 1	Partition 2
7724.Arm fail.			
Partition 1	Partition 2
7725.Kfb.panic			
Partition 1	Partition 2
7726.Kfb.medic.			
Partition 1	Partition 2
7727.Kfb.fire			
Partition 1	Partition 2
773.Expanders			
7731.Restarts			
PRF-LCD 0	INT-E 0x0C
PRF-LCD 1	INT-E 0x0D
PRF-LCD 2	INT-E 0x0E
PRF-LCD 3	INT-E 0x0F
INT-RX-S 0x07		

7732.Duress			
PRF-LCD 0	PRF-LCD 2
PRF-LCD 1	PRF-LCD 3
7733.Panic			
PRF-LCD 0	PRF-LCD 2
PRF-LCD 1	PRF-LCD 3
7734.Medical			
PRF-LCD 0	PRF-LCD 2
PRF-LCD 1	PRF-LCD 3
7735.Fire			
PRF-LCD 0	PRF-LCD 2
PRF-LCD 1	PRF-LCD 3
7736.Tamper			
PRF-LCD 0	INT-E 0x0C
PRF-LCD 1	INT-E 0x0D
PRF-LCD 2	INT-E 0x0E
PRF-LCD 3	INT-E 0x0F
INT-RX-S 0x07		
7737.Tmp.rest.			
PRF-LCD 0	INT-E 0x0C
PRF-LCD 1	INT-E 0x0D
PRF-LCD 2	INT-E 0x0E
PRF-LCD 3	INT-E 0x0F
INT-RX-S 0x07		
7738.3wrng.code			
PRF-LCD 0	PRF-LCD 2
PRF-LCD 1	PRF-LCD 3
7739.AC trouble			
INT-E 0x0C	INT-E 0x0E
INT-E 0x0D	INT-E 0x0F
7740.AC restore			
INT-E 0x0C	INT-E 0x0E
INT-E 0x0D	INT-E 0x0F
7741.BAT miss.			
INT-E 0x0C	INT-E 0x0E
INT-E 0x0D	INT-E 0x0F
7742.BATm.rest.			
INT-E 0x0C	INT-E 0x0E
INT-E 0x0D	INT-E 0x0F
7743.BAT low			
INT-E 0x0C	INT-E 0x0E
INT-E 0x0D	INT-E 0x0F
7744.BATl.rest.			
INT-E 0x0C	INT-E 0x0E
INT-E 0x0D	INT-E 0x0F

774.Syst.events			
PERF-Soft conn.	OUT1 trouble
SM start	OUT2 trouble
AC trouble	AUX trouble
BAT missing	KPD trouble
BAT low	DTA trouble
MS1 trouble	GSM trouble
MS2 trouble	Radio jamming
RTC setting		
775.Syst.rest.			
PERF-Soft disc.	OUT1 restore
SM end	OUT2 restore
AC restore	AUX restore
BAT miss.rest.	KPD restore
BAT low restore	DTA restore
MS1 restore	GSM restore
MS2 restore	Radio jam.rest.
RTC trouble		
776.Others			
PERFECTA restart	Manual test
RAM error	Period test
78.Assign 2			
781.Zones			
7811.Alarm			
Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32
7812.Al.restore			
Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22

Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32
7813.Tamper			
Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32
7814.Tamp.rest.			
Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32
7815.Bypass			
Zone 1	Zone 17
Zone 2	Zone 18

Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32
7816.Unbypass			
Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32
7817.Trouble			
Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31

Zone 16	Zone 32
7818.Trbl.rest.			
Zone 1	Zone 17
Zone 2	Zone 18
Zone 3	Zone 19
Zone 4	Zone 20
Zone 5	Zone 21
Zone 6	Zone 22
Zone 7	Zone 23
Zone 8	Zone 24
Zone 9	Zone 25
Zone 10	Zone 26
Zone 11	Zone 27
Zone 12	Zone 28
Zone 13	Zone 29
Zone 14	Zone 30
Zone 15	Zone 31
Zone 16	Zone 32
782.Partitions			
7821.Arm			
Partition 1	Partition 2
7822.Disarm			
Partition 1	Partition 2
7823.Al.clear			
Partition 1	Partition 2
7824.Arm fail.			
Partition 1	Partition 2
7825.Kfb.panic			
Partition 1	Partition 2
7826.Kfb.medic.			
Partition 1	Partition 2
7827.Kfb.fire			
Partition 1	Partition 2
783.Expanders			
7831.Restarts			
PRF-LCD 0	INT-E 0x0C
PRF-LCD 1	INT-E 0x0D
PRF-LCD 2	INT-E 0x0E
PRF-LCD 3	INT-E 0x0F
INT-RX-S 0x07		
7832.Duress			
PRF-LCD 0	PRF-LCD 2
PRF-LCD 1	PRF-LCD 3
7833.Panic			
PRF-LCD 0	PRF-LCD 2
PRF-LCD 1	PRF-LCD 3

7834.Medical			
PRF-LCD 0	PRF-LCD 2
PRF-LCD 1	PRF-LCD 3
7835.Fire			
PRF-LCD 0	PRF-LCD 2
PRF-LCD 1	PRF-LCD 3
7836.Tamper			
PRF-LCD 0	INT-E 0x0C
PRF-LCD 1	INT-E 0x0D
PRF-LCD 2	INT-E 0x0E
PRF-LCD 3	INT-E 0x0F
INT-RX-S 0x07		
7837.Tmp.rest.			
PRF-LCD 0	INT-E 0x0C
PRF-LCD 1	INT-E 0x0D
PRF-LCD 2	INT-E 0x0E
PRF-LCD 3	INT-E 0x0F
INT-RX-S 0x07		
7838.3wrng.code			
PRF-LCD 0	PRF-LCD 2
PRF-LCD 1	PRF-LCD 3
7839.AC trouble			
INT-E 0x0C	INT-E 0x0E
INT-E 0x0D	INT-E 0x0F
7840.AC restore			
INT-E 0x0C	INT-E 0x0E
INT-E 0x0D	INT-E 0x0F
7841.BAT miss			
INT-E 0x0C	INT-E 0x0E
INT-E 0x0D	INT-E 0x0F
7842.BATm.rest.			
INT-E 0x0C	INT-E 0x0E
INT-E 0x0D	INT-E 0x0F
7843.BAT low			
INT-E 0x0C	INT-E 0x0E
INT-E 0x0D	INT-E 0x0F
7844.BATI.rest.			
INT-E 0x0C	INT-E 0x0E
INT-E 0x0D	INT-E 0x0F
784.Syst.events			
PERF-Soft conn.	OUT1 trouble
SM start	OUT2 trouble
AC trouble	AUX trouble
BAT missing	KPD trouble
BAT low	DTA trouble
MS1 trouble	GSM trouble
MS2 trouble	Radio jamming
RTC setting		

785.Syst.rest.			
PERF-Soft disc.	OUT1 restore
SM end	OUT2 restore
AC restore	AUX restore
BAT miss.rest.	KPD restore
BAT low restore	DTA restore
MS1 restore	GSM restore
MS2 restore	Radio jam.rest.
RTC trouble		
786.Others			
PERFECTA restart	Manual test
RAM error	Period test
79.Test events			
791.At		
792.Disarmed		
793.Armed		
794.Options		
Independ.test		
8.Telephones			
81.Numbers			
811.Phone 1		
812.Phone 2		
813.Phone 3		
814.Phone 4		
815.Phone 5		
816.Phone 6		
817.Phone 7		
818.Phone 8		
82.AUDIO msg.			
Phone 1	Phone 5
Phone 2	Phone 6
Phone 3	Phone 7
Phone 4	Phone 8
83.SMS msg.			
Phone 1	Phone 5
Phone 2	Phone 6
Phone 3	Phone 7
Phone 4	Phone 8
84.Unknown SMS			
Phone 1	Phone 5
Phone 2	Phone 6
Phone 3	Phone 7
Phone 4	Phone 8

85.Listening-in			
Phone 1	Phone 5
Phone 2	Phone 6
Phone 3	Phone 7
Phone 4	Phone 8
86.List.durat.		
87.List.aft.msg			
Phone 1	Phone 5
Phone 2	Phone 6
Phone 3	Phone 7
Phone 4	Phone 8
88.Names			
881.Phone 1		[Phone 1]
882.Phone 2		[Phone 2]
883.Phone 3		[Phone 3]
884.Phone 4		[Phone 4]
885.Phone 5		[Phone 5]
886.Phone 6		[Phone 6]
887.Phone 7		[Phone 7]
888.Phone 8		[Phone 8]
89.On arm.part.			
Partition 1	Partition 2
9.AUDIO messag.			
91.Options			
AUDIO messag.	Double v.message
93.Partition 1			
931.Arm		
932.Disarm		
933.Alarm clear		
934.Arm fail.		
935.Alarm		
936.Tamper		
937.Tamp.rest.		
938.Panic		
939.Medical		
9310.Fire		
9311.Duress		
94.Partition 2			
941.Arm		
942.Disarm		
943.Alarm clear		
944.Arm fail.		
945.Alarm		
946.Tamper		
947.Tamp.rest.		
948.Panic		
949.Medical		

9410.Fire	
9411.Duress	
95.Troubles		
951.BAT low	
952.BATI.rest.	
953.AC trbl.	
954.AC rest.	
955.GSM tr.rest	
96.Outputs		
961.Output 1	
962.Output 2	
963.Output 3	
964.Output 4	
965.Output 5	
966.Output 6	
967.Output 7	
968.Output 8	
969.Output 9	
9610.Output 10	
9611.Output 11	
9612.Output 12	
9613.Output 13	
9614.Output 14	
9615.Output 15	
9616.Output 16	
10.SMS messagin		
100.Options		
SMS messaging	Messaging events
101.Phone 1		
Partition 1	Bypass
Partition 2	Troubles
Alarm	Function
Arm/Disarm/Clear	System
102.Phone 2		
Partition 1	Bypass
Partition 2	Troubles
Alarm	Function
Arm/Disarm/Clear	System
103.Phone 3		
Partition 1	Bypass
Partition 2	Troubles
Alarm	Function
Arm/Disarm/Clear	System
104.Phone 4		
Partition 1	Bypass
Partition 2	Troubles
Alarm	Function
Arm/Disarm/Clear	System

105.Phone 5			
Partition 1	Bypass
Partition 2	Troubles
Alarm	Function
Arm/Disarm/Clear	System
106.Phone 6			
Partition 1	Bypass
Partition 2	Troubles
Alarm	Function
Arm/Disarm/Clear	System
107.Phone 7			
Partition 1	Bypass
Partition 2	Troubles
Alarm	Function
Arm/Disarm/Clear	System
108.Phone 8			
Partition 1	Bypass
Partition 2	Troubles
Alarm	Function
Arm/Disarm/Clear	System
11.SMS control			
111.USSD SIM1		
112.USSD SIM2		
113.Chk.credit1		
114.Chk.credit2		
115.PERF.Soft		
116.Download FW		
117.Update FW		
118.SMS control			
1181.SMS 1		
1182.SMS 2		
1183.SMS 3		
1184.SMS 4		
1185.SMS 5		
1186.SMS 6		
1187.SMS 7		
1188.SMS 8		
1189.SMS 9		
11810.SMS 10		
11811.SMS 11		
11812.SMS 12		
11813.SMS 13		
11814.SMS 14		
11815.SMS 15		
11816.SMS 16		
119.SMS funct.			
1191.Funct.1		

1192.Funct.2		
1193.Funct.3		
1194.Funct.4		
1195.Funct.5		
1196.Funct.6		
1197.Funct.7		
1198.Funct.8		
1199.Funct.9		
11910.Funct.10		
11911.Funct.11		
11912.Funct.12		
11913.Funct.13		
11914.Funct.14		
11915.Funct.15		
11916.Funct.16		
1110.Any number		
12.Others			
121.Schedules			
1211.Schedule 1			
Arm [✓]	Code change [✓]
Disarm [✓]	Users edit [✓]
Alarm clear [✓]	Outputs control [✓]
Duress	Tests [✓]
Zone inhibit [✓]	Service access
Zone isolate	ID change
1212.Schedule 2			
Arm [✓]	Code change [✓]
Disarm [✓]	Users edit
Alarm clear [✓]	Outputs control [✓]
Duress	Tests
Zone inhibit	Service access
Zone isolate	ID change
1213.Schedule 3			
Arm [✓]	Code change [✓]
Disarm	Users edit
Alarm clear	Outputs control
Duress	Tests
Zone inhibit	Service access
Zone isolate	ID change
1214.Schedule 4			
Arm [✓]	Code change
Disarm [✓]	Users edit
Alarm clear [✓]	Outputs control
Duress [✓]	Tests
Zone inhibit	Service access
Zone isolate	ID change

1215.Schedule 5			
Arm[✓]	Code change[✓]
Disarm[✓]	Users edit[✓]
Alarm clear[✓]	Outputs control[✓]
Duress	Tests[✓]
Zone inhibit[✓]	Service access[✓]
Zone isolate[✓]	ID change[✓]
1216.Sch.1 name			[Normal]
1217.Sch.2 name			[Simple]
1218.Sch.3 name			[Arms only]
1219.Sch.4 name			[Duress]
1210.Sch.5 name			[Master]
122.Kfb.funct.			
1221.Button ○			
1222.Button □			
1223.Button ▲			
1224.Button ■			
1225.Button ●			
1226.Button ○+●			
123.Max.AC loss			[1 min]
124.Al.duration			[30 s]
125.Suppr.arm			
126.Options			
Grade2	Trbl.in part.arm
Troubles memory[✓]	No SATEL trouble
3wrng.codes=blk.[✓]	No jamm. trouble
No AC=no bcklght[✓]	Check if ready[✓]
Restore events[✓]	Arm ExDly w.trbl[✓]
Events limitat.[✓]	Tamper = no arm
Tmp.on ext.siren[✓]	BAT low = no arm
Tmp.on int.siren[✓]		
127.Radio devs			
1271.Add			
1272.Filter			
1273.Remove			
1274.Out.tamper			
1275.Al.signal.			
1276.Acknowled.			